
MTO

# Twiggy Bed

King


Thank you for purchasing this Twiggy Bed. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.




## PRE-ASSEMBLY PREPARATION

Please ensure instructions are read in full before attempting to assemble this product.

**Necessary Tools**







(NOT INCLUDED)

Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact customer services on 01244 689949 or email mail@fwgroup-uk.com.

This product is **HEAVY.** It should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.







This product takes approximately **40 MINUTES** to assemble with **2 PEOPLE.**
Do not use power tools to assemble.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN.**







Read this leaflet in full before commencing assembly.

# Fittings and parts checklist

## Fittings

| | | | | | |
|---|---|---|---|---|---|
| **A** | M4 Allen Key x 1pc |  | **E** |  | M6 X 25mm Bolt x 10pcs |
| **B** | M5 Allen Key x 1pc |  | **F** |  | M8 Spring Washer x 4pcs |
| **C** | Centre Caps x 8pcs |  | **G** |  | M8 Nut x 4pcs |
| **D** | Side Caps x 16pcs |  | **H** |  | Screw 3.5 X 30mm x 4pcs |
| **E** | Wide Centre Caps x 8pcs |  | **I** |  | M13 Spanner x 1pc |
| **F** | Wide Side Caps x 16pcs |  | | | |

## Parts


| | | |
|---|---|---|
| **1** | Headboard x 1 |  |
| **2** | Footboard x 1 |  |
| **3** | Side Rails x 2 |  |
| **4** | Slats x 16 |  |
| **5** | Wide Slats x 16 |  |
| **6** | Centre Rail x 1 |  |
| **7** | Legs x 4 |  |
| **8** | Metal Plates x 4 |  |

# Step by step assembly instructions

## Step One

Place Metal Bracket on Side Rails (3) over pre-inserted bolts in Headboard (1) and Footboard (2) and hand-tighten to loosely secure parts together. Do not tighten bolts with M5 Allen Key (B) until you have inserted the Centre Rail in the next step.

Fig.1




**LOOSELY SECURE PARTS TOGETHER IN ORDER FOR CENTRE RAIL TO FIT IN NEXT STEP**






Fig.2




## Step Two

Lower the Centre Rail (6) into the brackets in the centre of the Headboard and Footboard as shown in fig.3. Now secure the Centre Rail using M6 x 25mm Bolts (G) and tighten with M4 Allen Key (A) as shown in fig.4. You can now tighten the bolts at the Side Rails from previous step (Step One) with the M5 Allen Key (B) so all fastenings are now tightened.

Fig. 3









Fig. 4




**AFTER INSERTING CENTRE RAIL, TIGHTEN ALL FIXINGS FULLY INCLUDING BOLTS AT SIDE RAILS (FROM STEP ONE)**





| G. | A. | B. |
|---|---|---|
|  |  |  |
| M6 x 25mm x 2 | M4 Allen Key x 1 | M5 Allen Key x 1 |


## Step Three

Attach the Metal Plate (8) to the bottom of Headboard and Footboard using Bolt M6 x 25mm (G)x2. Do not tighten the bolt until you make adjustment for screw hole at Side Rail. Next, insert Screw 3.5 x 30mm (J) and tighten the bolt using M4 Allen Key (A). Insert Leg (7) into the bottom of Metal Plate (8) using M8 Spring Washer (H) and M8 Nut (I). Hold the M8 Nut (I) using M13 Spanner (K) and twist the Leg (7) to secure in place.
Repeat for the other 3 legs.


For Headboard




For Footboard




**AFTER INSERTING BOLT M6 x 25MM, MAKE ADJUSTMENT FOR SCREW HOLE, THEN INSERT THE SCREW 3.5 X 30MM. THEN TIGHTEN THE BOLT AND SCREW FIXINGS FULLY.**





**TWIST WOODEN LEG ONLY WITHOUT MOVING THE M8 NUT, SPRING WASHER AND SPANNER**


| | | | | | | | |
|---|---|---|---|---|---|---|---|
| H.<br>M8 Spring Washer x 4 | 7.<br>Legs x 4 | 8.<br>Metal plates x 4 | K.<br>M13 Spanner x 1 | I.<br>M8 Nut x 4 | J.<br>Screw 3.5 x 30mm x 4 | G.<br>M6 x 25mm Bolt x 8 | A.<br>M4 Allen Key x 1 |


# Step Four

With the curved side facing upwards, insert 2 slats into a centre cap then into 2 side caps on either end(x16). (Please note the Wide Slats must be inserted with the Wide Centre Caps (E) and Wide Side Caps (F)). Repeat this process for all slats.

Note: Please see the Diagram 1 below to arrange the slat with the correct system).




# Step Five

This bed is now ready to use.



## Care and Maintenance

This bed should be cleaned using a soft, damp cloth and dried immediately.

Do not use a very wet cloth or allow any liquid contact for a long period of time as this can permanently damage the surface.

Do not use detergents and do not rub as this can cause permanent damage.

Always protect your bed from direct sunlight as this may accelerate the natural ongoing discolouration process.

Bolts holding together the bed frame should be tightened regularly.

Please retain this information leaflet for future reference.

This product complies with BS EN 1725:1998.

## Safety Instructions

Never drag furniture when moving it. Always lift it.
Periodically check all fixings to ensure none have come loose and re-tighten where necessary.
Please take care when handling or moving the furniture as careless handling may cause damage or injury.
Furniture can be dangerous if incorrectly installed. Any assembly should be carried out by a competent adult.
No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.
During assembly, children should be kept away from the product due to possible risk of injury.
Do not use this item if any components are missing or damaged.
It is recommended that care is taken when moving heavy objects to a new location to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

If you require any additional information or have any issues with this product please call the customer services helpline on 01244 689949 or email mail@fwgroup-uk.com.