







If width (X) is greater than 100mm or height (Y) greater than 100mm STOP installation now and contact the customer help line.




1 Measure the TV Fixing Holes



TV Screws and Spacers




Boxed Parts




Tools Recommended

4 Attach the TV

Attaching




TV Levelling



Check all fittings are tight

JZL100

Leaflet No. **463440** rev01



Read through **ALL** instructions before commencing installation. If you have any questions about this product or issues with installation contact the customer services helpline before returning this product to the store. See jl.avfgroup.com/p/jzl100 for more information.

CUSTOMER SERVICES HELP LINE NUMBER:
01952 670009

33lbs
15kg

25"
63cm


AVF Group Ltd. Hortonwood 30, Telford, Shropshire, TF1 7YE, England

2

Fitting the TV Bracket

No Spacers


For TVs with flat/unobstructed back




Spacers

G



For TVs with irregular/obstructed back



WARNING



After completing step 2 you will have fittings left over, please keep for future reference.







C x3

Attach the bracket to the back of your TV using suitable screw and spacer combinations.

3

Fitting the Wall Bracket

Solid Wall



Lubricate screw thread with soap.




DO NOT over tighten screws. Tighten screws by hand only.


D x3

E x3

Wood Stud



Ensure bracket is in the centre of the wood stud.



Lubricate screw thread with soap.



DO NOT over tighten screws. Tighten screws by hand only.

E x3