

Wilton 150cm Bedstead

King

Stock number natural: 803/42904


Stock number white: 803/42422

Stock number dark: 803/42522

For product support or spare parts
please call the John Lewis Helpline;

Tel: 01244 - 689949

e-mail: mail@fwgroup-uk.com



Pre-assembly Preparation

Please ensure instructions are read in full before attempting to assemble this product.

Necessary Tools



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the John Lewis Helpline.

This product is **HEAVY**. It should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.

This product takes approximately **40 MINUTES** to assemble with **2 PEOPLE**.




The fittings pack contains **SMALL PARTS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.


If you require any additional information or have any issues with this product please call the John Lewis Helpline on 01244 - 689949 or e-mail: mail@fwgroup-uk.com

Fittings and parts checklist

Fittings

A	Allen key x 1 (4mm)		B	M8 bolt x 8 (15mm)	
C	Screw x 6 (30mm)				


Bedstead parts



Step by step assembly instructions


Step One

Attach the Side Rails (3) to the Footend (2) using Bolts M8 (B) and hand-tighten bolts to loosely secure parts together. Do not tighten with Allen Key (A) until you have inserted the Centre Rail in Step Three.





Step Two

Attach the Side Rails (3) to the Headend (1) using Bolts M8 (B) and hand-tighten bolts to loosely secure parts together. Do not tighten with Allen Key (A) until you have inserted the Centre Rail in Step Three



Step Three


Slot the Centre Rail into the brackets on the Headboard (1) and Footboard (2). You can now tighten the bolts with the Allen Key (A) at the Side Rails from the previous steps so all fastenings are now tightened.



AFTER INSERTING CENTRE RAIL, TIGHTEN ALL FIXINGS FULLY INCLUDING BOLTS AT SIDE RAILS (FROM STEPS ONE AND TWO)

Step Four

Fit the Slats (5) to the Side Rails (3) and secure the top, bottom and centre slat with Screws 30mm (C).



This bed is now ready to use.

Care and Maintenance

Wood Furniture

Wood displays different grain patterns depending on which way they cut - for example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber - these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.

Wood veneers also allow distinctive patterns to be created on flat surfaces, such as table tops and drawer fronts by the way the slivers are arranged.

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

How to care for your wood furniture

Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.

Waxed furniture will need to be given a coat of beeswax a couple of times a year to help maintain its lustre.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time.

Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping.

Safety Instructions

Never drag furniture when moving it. Always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury. Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent adult. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture. During assembly children should be kept away from the product due to possible risk of injury. Do not use this item if any components are missing or damaged.

It is recommended that before moving heavy objects to a new location they are completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

This product complies with BS EN 1725:1998.

If you require any additional information or have any issues with this product please call the John Lewis Helpline on 01244 689949 or email mail@fwgroup-uk.com

John Lewis Partnership 171 Victoria Street, London, SW1E 5NN.
www.johnlewis.com