


JZL4701


Leaflet No. **464012** rev03



*Read through **ALL** instructions before commencing installation. If you have any questions about this product or issues with installation contact the customer services helpline before returning this product to the store. See jl.avfgroup.com/p/jzl4701 for more information.*

CUSTOMER SERVICES HELP LINE NUMBER:


01952 670009




AVF Group Ltd. Hortonwood 30, Telford, Shropshire, TF1 7YE, England

Assembly Overview



Fit the TV Brackets



Fit the Wall Bracket



Connect the TV



Tilt (if required)

Index

1 Measure the TV fixing holes Width and Height

2 Preparing the TV Brackets

3 Fitting the TV Brackets

4 Fitting the Wall Bracket

5 Connecting the TV

Retain all packaging in case the bracket needs to be returned.

Contents may vary from photography/ Illustrations.


You will not need all these parts, so expect there to be some left over depending upon the specification of your TV.

This product is intended for indoor use only. Use of this product outdoors could lead to failure and personal injury.


It is the responsibility of the installer to ensure that the mounting wall is of a suitable standard and void of any services (eg gas, electricity, water etc).

AVF accept no responsibility for any damage or loss caused by installing this product in a sub standard wall.


Tools Recommended



Boxed Parts




TV Screws, Reducers and Spacers




M4

D1 x4




M4

D2 x4




M5

D3 x4




M5

D4 x4




M6

D5 x4




M6

D6 x4




M8

D7 x4



M8

D8 x4



M8

D9 x4



E1 x4




E2 x4




F1 x4



F2 x4




J x4



K x4




L x1

1**Measure the TV fixing holes Width and Height**

If width (X) is greater than 400mm or height (Y) greater than 400mm
STOP installation now and contact the customer help line


You are provided with 4 diameters of TV fixing screws, **M4**, **M5**, **M6** and **M8**. Determine the screw diameter that fits and remember for step 3.



2

Preparing the TV Brackets


To ensure maximum tilt is possible after installation you will need to ensure that your TV does not clash with the wall.



If a clash is observed you have 2 options:


Option 1

Move Bracket **B** closer to the bottom of your TV



Option 2

Use spacers **F2** to raise Bracket **B**




3

Fitting the TV Brackets


No Spacers

For Tvs with flat/unobstructed back




Spacer **F1/F2**



For Tvs with irregular/obstructed back



WARNING



After completing step 3 you will have fittings left over, please keep for future reference





Attach the bracket to the back of your TV using suitable screw, reducer and spacer combinations.

4



Fitting the Wall Bracket

Solid Wall





Remove dust from hole


Wood Stud



Ensure bracket is in the centre of the wood stud



12.5 mm (1/2") MAX




A

J

K




Lubricate screw
thread with soap



J

x4




K


x4



DO NOT over tighten screws
Tighten screws by hand only




Lubricate screw
thread with soap



A

J



J

x4




DO NOT over tighten screws
Tighten screws by hand only

5

Connecting the TV

Attaching



TV Levelling

