John Lewis

Alexia 2 Drawer Dressing Table

Stock number:80300509

Thank you for purchasing this product. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product



Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product

Necessary Tools





Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product. (Include if relevant)

This product takes approximately **30 MINUTES** to assemble with **2 PERSON**.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.


Fittings and parts checklist

А	M6 x 25mm x 5pcs			(1)	Glass Top x 1pcs	
В	M8 x 40mm x 4pcs	O				
C	M6 x 10mm x 8pcs	and a second		(2)	Left Leg x 1pcs	
D	Spring Washer (m6) x 13pc	Ø				
E	Metal Washer (m6) x 13pcs	\bigcirc		(3)	Right Leg x 1pcs	
F	4mm Allen key x 1pcs					
G	Spring Washer (m8) x 4pc	\bigcirc		(4)	Cross bars x 1pcs	
н	5mm Allen key x 1pcs			-		
				(5)	Back support x 1pcs	

Step by step assembly instructions


Step One

1.Use bolt(C)X8, spring washer (D)X8 and metal washers(E)X8 to attach the Back support (5) onto Left leg(2), Right leg (3), and tighten with Allen Key F. Remarks: (The connecting metal tab are on the back side of the Left leg (2) and Right Leg (3))




Step Two

1.Use bolt (B)x4, Spring Washer (G)x4 to attach the Cross bar (4) onto both Legs and tighten with Allen Key (H).



Step Three

1. Attach Glass top 1 to Cross bar (4) using 5 x bolts (A), 5 x spring washer (D) and 5 x metal washers (E). Tighten using Allen key (F)




Step Four


1.This item comes pre-fitted with two wall attachment straps. Attach the ends of the wall attachment straps to the wall once the item has been placed into the required position using appropriate screws, washers and wall plugs for your wall type.

WARNING: Ensure the area to be drilled is free from hidden electrical wires and water or gas pipes.


NOTE: Wall fixings are not included. Source suitable fixings for your wall type, if in doubt consult a qualified tradesperson




Wall fixing - if in doubt seek professional advice



Wood If fixing to wood make sure that it isn't chipboard as screws can easily pull away from the core structure



Brick or Masonry Use an appropriate wall plug provided you are sure your wall is sound



Cavity wall Special toggle wall plugs are needed. Seek expert advice

Care and Maintenance

Use glass cleaner or soapy water for cleaning, do not use anything abrasive as this may damage the surface of the product.

Protect surfaces from scratches and marks by using mats and coasters

General warnings:

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury. Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly insalled or assembled furniture.

Specific warnings for heavy items:

It is recommended that before moving heavy objects to a new location they are completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

John Lewis Partnership 171 Victoria Street London SWIE 5NN

www.johnlewis.com