## **Alexia 3 Drawer Chest Mirror**

Stock number:80300508

Thank you for purchasing this product. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product



#### Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product

#### **Necessary Tools**



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact your local John Lewis Branch or our Online Team

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury or damage to the product.

This product takes approximately **30 MINUTES** to assemble with **1 PERSON**.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.


# Fittings and parts checklist

Α	M6×25mm x 5pcs		(1)	Top x 1 pcs	
В	Spring washer x5pcs				
С	Metal Washer x 5pcs	0			
D	4 Allen key × 1pcs		(2)	Leg x 1 pcs	

# Step by step assembly instructions

## Step One


1. Attach leg 2 To Top using 5 x bolts (A), 5 x spring washer (B) and 5 x metal washers (C). Tighten using Allen key (D)




### Step Two

**1.**This item comes pre-fitted with two wall attachment straps. For additional stability it is advised that this is placed against the wall if heavy items are placed inside the drawers . If you do want to fix this product against the wall attach the ends of the wall attachment straps to the wall once the item has been placed into the required position using appropriate screws, washers and wall plugs for your wall type.

**NOTE**: Wall fixings are not included. Source suitable fixings for your wall type, if in doubt consult a qualified tradeperson.




## Wall fixing - if in doubt seek professional advice



Wood
If fixing to wood
make sure that it
isn't chipboard as
screws can easily
pull away the core
structure


Wood

If fixing to wood
make sure that it
isn't chipboard as
screws can easily
pull away from the
core structure



Brick or masonry use the wall plug from the pack, provided you are sure that your wall is sound.

Brick or Masonry Use an appropriate wall plug provided you are sure your wall is sound



Cavity wall. Special toggle wall plugs needed. Seek expert advice

> Cavity wall Special toggle wall plugs are needed. Seek expert advice

#### Care and Maintenance

Use glass cleaner or soapy water for cleaning, do not use anything abrasive as this may damage the surface of the product.

Protect surfaces from scratches and marks by using mats and coasters.

### **General warnings:**

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary. Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly insalled or assembled furniture.

#### Specific warnings for heavy items:

It is recommended that before moving heavy objects to a new location they are completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

#### PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

John Lewis Partnership 171 Victoria Street London SW1E 5NN <a href="https://www.johnlewis.com">www.johnlewis.com</a>