



# Assembly instructions for James Floor Lamp

70682170

Thank you for purchasing this James Floor Lamp. Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

## Warning

Please read these instructions carefully before commencing any work.

Always use the correct type and wattage bulb. Never exceed the wattage stated.

When changing the bulb, ensure the product is unplugged and always allow the old bulb to cool down before handling.

Dispose of used bulbs carefully.

Keep instructions for future reference.

Your floor lamp has been packaged as six parts to prevent damage during transit.

Please follow these assembly instructions carefully:

1) Remove all packaging from the base, the two stem sections, the arm assembly, the head and the counter balance weight

2) Place base (G) on a firm, flat surface and screw on tube (F) in a clockwise direction, followed by tube (E). Take care not to trap the cable or cross the thread, firmly tighten the tube by hand.

3) Pull any excess cable through from the side of the base. Turn the arm assembly anti-clockwise approximately 6 times (Turning anticlockwise first, ensures that the cable will straighten when tubes are fully assembled). Screw assembly (C) in a clockwise direction on to tubes (E&F). Take care not to trap the cable or cross the thread, firmly tighten the tube by hand.


4) Screw counter balance weight (D) on to the end of the arm assembly (C) in a clockwise direction.

5) Remove shade ring (B) from the lampholder, place the shade (A) over the lampholder. Refit the shade ring. Tighten to secure the shade in place.

6) Fit a suitable 60W ES GLS light bulb or 12w energy saver light bulb. Do not exceed the wattage as recommended as this may cause damage to the light fitting.

Your floor lamp is now ready for use.

Switch on using the rocker switch situated on the head.



We have taken great care to ensure that this product reaches you in perfect condition. However, should any parts be damaged or missing please contact our Product Helpline on (01202) 690945. We will despatch to you, within 7 working days, your missing/damaged part. When phoning please ensure you have the following information available: Name and Address, Daytime Telephone Number, Store and Date of Purchase, Product Reference (on base or on box label), Description of Missing/Damaged Part. This does not affect your statutory rights.