AURELIA 2 DOOR WARDROBE

Stock number: 803 053 17

Thank you for purchasing this 2 DOOR WARDROBE. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product



Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product

Necessary Tools



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE** WHEN LIFTING THE PRODUCT TO AVOID PERSOANAL INJURY AND DAMAGING THE PRODUCT.


This product takes approximately 45 MINUTES to assemble with 2 PEOPLE.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Fittings and parts checklist

Α	Wood Screw (M4x40)	x44	Jaman	В	Key	x 1	8
С	Wood Screw (M3x30)	x38	()	E	Washers X38	screw caps	ිරිර


Note: Place washer (E) over screw (C) before using.



Item	Description	Qty	Item	Description	Qty
1	BOTTOM PANEL/BASE	1	2	LH SIDE PANEL	1
3	RH SIDE PANEL	1	4	HANGING RAIL	2
5	FRONT FRAME WITH TWO DOORS	1	6	TOP	1
7	BACK PANELS	2			

Step by step assembly instructions

Step One




Place the LH side panel (2) onto the bottom panel, ensuring it is properly secured in existing holes in the base, then attach with screws (A) trough batons. Repeat step for RH side panel (3) .

Step Two




Place the front frame with two doors (5) and attach to side walls and bottom panel/base with screws (A) thought the batons.

Step Three




Place the top (6) and attach with screws (A) to side panels(3) and front frame, again through batons.

Step Four




Insert the hanging rails(4) in the support brackets.

Step Five



Insert the back panels(7) as shown and attach with screws(C) provided

Finish



Care and Maintenance

How to care for your wood furniture

Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.

Waxed furniture will need to be given a coat of beeswax a couple of times a year to help maintain its luster.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time.

Make sure all surfaces are protected from heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.

Extendable dining tables should be left extended for the first few months to avoid an uneven appearance. Likewise, lamps and ornaments should also be moved regularly.

Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping

Safety Instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary. Please take care when handling or moving the furniture as careless handling may cause damage or injury. Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly insalled or assembled furniture.

It is recommended that before moving heavy objects to a new location they are completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

John Lewis Partnership 171 Victoria Street London SWIE 5NN www.johnlewis.com