

Thank you for purchasing this chest. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



For spare parts, please contact the
WG John Lewis helpdesk on 0845 606 7004

Care and Maintenance

This product should be, for general cleaning, dust weekly with a soft lint free cloth.
Do not use furniture polish. Any spills should be removed immediately with a soft clean cloth.
Do not rub or scrub the surface when cleaning.
Do not use abrasive cleaning products or those containing silicone.

Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping.

Never drag furniture when moving it, always lift it.

Important Safety Note

No liability will be accepted for damage or injury caused by inadequate fixing or use without fixing.

Please retain this information leaflet for future reference.