


John Lewis

2M Glass Dining Table

Stock number: 877/12803

Thank you for purchasing this dining table. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product



Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product

Necessary Tools





Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

This product takes approximately **15 MINUTES** to assemble with **1 PERSON**.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.

Fittings and parts checklist


A	Allen Key (4mm) x 1		E	Screws (M6X85) x 4	
B	Allen Key (5mm) x 1		F	Glass with aluminium disc x 1	
C	Screws (M6X15) x 8		G	Cross bar x 2	
D	Screws (M8X25) x 8		H	Legs x 2	

Step by step assembly instructions

Note: Please do not fully tighten all screws until you finish assembling all parts, then go back and fully tighten all screws, this will make it easier during assembly of unit.


Step One

Put the cross bars (G) between two legs (H) and align the screw holes. Use Allen Key (A) to tighten all the screws (C) first.




Step Two

Put the leg (H) and cross bar (G) on the bottom of glass with aluminium disc (F) and align the screw holes. Use Allen key (A) to tighten all the screws (E). Then, use Allen key (B) to tighten all the screws (D).



Step Three

1. Finished the assembly.



Care and Maintenance

Glass furniture

Use glass cleaner or soapy water for cleaning, do not use anything abrasive as this may damage the surface of the product.

Protect surfaces from scratches and marks by using mats and coasters.

Metal

Protect metal from spillage, sunlight and heat. A slightly damp cloth is the best cleaning agent for the material.

Do not use any abrasive cleaner or harsh detergent as this can damage the surface.

Avoid spilling or dropping crumbs of food with a high fat content on the surface as this can permanently mark the metal.

Safety Instructions

General warnings:

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

Specific warnings for tables with glass:

If the glass is chipped or broken stop using the product and consult the manufacturer or supplier.

WARNING:

a) Do not place very hot or very cold items on the glass surface(s) unless adequately thick table mats are used to prevent such items from coming into contact with the glass.

b) Do not sit or stand upon the glass surface(s)

c) Do not use the glass as a chopping surface. Do not strike the glass with hard or pointed items.

d) When cleaning glass panels use a damp cloth or leather with washing up liquid or soft soap if necessary; do not use washing powders or any other substances containing abrasives since these substances scratch glass.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

John Lewis Partnership 171 Victoria Street London SW1E 5NN
www.johnlewis.com