


John Lewis

NOAH – LGE BENCH 185, OAK - SML BENCH 145, OAK

Stock number: 836/24801
836/24802

Thank you for purchasing this Noah bench. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product.

Necessary Tools









Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

This product takes approximately **20 MINUTES** to assemble with **2 PEOPLE**.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.


Fittings and parts checklist

A	ALLEN Bolts x 7		C	ALLEN Key x 1	
B	Washers x 7				
1	Base sides (legs) x 2		3	Bench top x 1	
2	Middle stretcher x 1				

Step by step assembly instructions


Step One

1. Carefully unpack master carton, containing bench top, two bench base sides (legs), middle stretcher and small box of hardware.
2. Assemble the bench on a flat clean soft surface to prevent damage. Place bench top on this surface facing upside down.




Step Two

1. Attach base side (1) to the base rail (see dowels) on your right side.
2. Two joints between the base side (1) and base rails secure with bolt (A) and washer (B)
3. Tighten with Allen key (C)




Step Three

1. Attach base middle stretcher (2) to the left side table base (1) and secure joint with bolt (A) and washer (B).
2. Tighten with Allen key (C).




Step Four

3. Attach left side of the table base (1) with stretcher (2) to the right side base and base rails and secure all three joints with bolts (A) and washers (B).
4. Tighten with Allen key (C).



Step Five

1. Secure middle stretcher (2) and bench top (3) with Allen bolt (A) and Washer (B).
2. Tighten with Allen key (C).



Care and Maintenance

Wood Furniture

Wood displays different grain patterns depending on which way they cut - for example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber - these are just characteristics of the natural beauty of the wood.

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

How to care for your wood furniture

Furniture with hard lacquer surface should be dusted with a dry cloth.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time.

Make sure all surfaces are protected from heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.

Extendable dining tables should be left extended for the first few months to avoid an uneven appearance. Likewise, lamps and ornaments should also be moved regularly.

Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping

Safety Instructions

General warnings:

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

Specific warnings for heavy items:

It is recommended that before moving heavy objects to a new location they are completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

John Lewis Partnership 171 Victoria Street London SW1E 5NN
www.johnlewis.com