For use

We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will damage the finish.

Recommended bulb

I x 40W SES Golf or Ix 3W SES Dimmable LED Energy Efficient Golf Ball or I x 28W SES Eco Halogen Golf Ball When changing a bulb, always switch off at the mains and allow the bulb to cool before

handling. Dispose of used bulbs carefully. Do not exceed the wattage stated or use a different shape bulb from that indicated on the fitting.

Specification

Maximum wattage: 40W Voltage: 240V, 50Hz IP Rating: 20 Weight: 2.1kg



X


This symbol indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis do not operate instore take back, but as members of the Distributor Trade Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.

We have taken great care to ensure that this product reaches you in perfect condition. However, should any parts be damaged or missing please contact our Product Helpline on (01202) 690945.

John Lewis Partnership **171** Victoria Street London SWIE 5NN johnlewis.com

John Lewis

User Manual Chelsea Table Light



Thank you for purchasing the Chelsea Task Lamp. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product. Please keep these instructions for future reference.

Warnings!

Please read these instructions carefully before commencing any work.

For your safety, always switch off the supply before changing lightbulbs, cleaning or removing shades. Always take care when handling lightbulbs to avoid injury in case of breakage. If the flexible external cable becomes damaged, it should only be replaced by the manufacturer or suitably qualified person.



This product is Class II (double insulated) and must not be earthed.





Assembly

Carefully unpack the carton, making sure all the parts are present before assembly.

Step I

Fit the recommended bulb as per the details overleaf. Please note the dimmer will not function if a bulb of less than 25W is used. Suitable dimmable LED energy saving bulbs may be used, please check compatibility of bulbs before installing.

Step 2

Plug into the mains and switch on by touching the metal base. There are three levels of brightness - touch to turn on, to increase the brightness, and then to turn off. The head tilt can be adjusted using the handle. Be aware the shades can get hot, please only use

the handle. Your table lamp is now ready for use.