














IMPORTANT: please ensure you assemble all parts loose first so that the last remaining parts can fit. After all parts are in the required location holes, then tighten all parts so the furniture is secure.

NOTE: Once fully assembled, depending on the ground, occasionally a foot may appear not to touch the ground due to unavoidable iron features and the structure. This does not affect the function or safety of this furniture and should not affect the design appeal of the furniture in your outdoor environmen.

ASSEMBLY INSTRUCTION

| 一、Parts list | | | | | |
|--------------|---|-----|------|---|-----|
| DESC | Diagram | QTY | DESC | Diagram | QTY |
| A |  | 1 | B |  | 1 |
| C |  | 1 | D |  | 1 |
| E |  | 2 | F |  | 1 |
| G |  | 16 | H |  | 1 |
| I |  | 6 | | | |

二、Assembly Steps

| | |
|---|--|
|  <p>Step 1</p> |  <p>Step 2</p> |
|  <p>Step 3</p> |  <p>Step 4</p> |

NOTE: Find the screw caps already attached to the bolt section. Please remove these first then assemble the product as per Instruction.