BAROQUE NON ELEC PENDANT

IL2744

Thank you for buying this **Baroque** non-electrical pendant.

Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

Make sure the electricity is switched off at the fuse board before removing bulb.

- 1. Ensure the lamp holder is in good condition and is not damaged before proceeding.
- Allow the old bulb to cool down before handling. Remove existing light bulb from lamp holder.
- 3. Remove lower half of lamp holder and make sure lamp holder is not damaged.
- If required, clip the reducing ring into top ring of the shade.
- Place upper half of lamp holder, attached to cable, through top ring of shade. Replace lower half of lamp holder to hold the pendant in place.
- 6. Carefully remove all of the packaging that has been added to protect the droppers and chains in transit, take care not to pull the packaging as this will damage the chains.
- Fit the bottom dropper to the centre bottom of the frame taking care to ensure that the dropper is securely attached.
- 8. Fit the bulb, type and wattage as indicated on the product.
- 9. Switch the electricity back on at the fuse board. You may now switch on the light. Your non-electric shade is now ready for use.


Please retain this information leaflet for future reference

GENERAL INFORMATION

This fitting is designed for internal use only

Do not use polish or abrasive cleaner – just a soft dry cloth.

John Lewis Partnership 171 Victoria Street London SW1E 5NN www.johnlewis.com Issue 1 11/13



BAROQUE NON ELEC PENDANT

IL2744

Thank you for buying this **Baroque** non-electrical pendant.

Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

Make sure the electricity is switched off at the fuse board before removing bulb.

- 1. Ensure the lamp holder is in good condition and is not damaged before proceeding.
- 2. Allow the old bulb to cool down before handling. Remove existing light bulb from lamp holder.
- 3. Remove lower half of lamp holder and make sure lamp holder is not damaged.
- If required, clip the reducing ring into top ring of the shade.
- 5. Place upper half of lamp holder, attached to cable, through top ring of shade. Replace lower half of lamp holder to hold the pendant in place.
- 6. Carefully remove all of the packaging that has been added to protect the droppers and chains in transit, take care not to pull the packaging as this will damage the chains.
- 7. Fit the bottom dropper to the centre bottom of the frame taking care to ensure that the dropper is securely attached.
- 8. Fit the bulb, type and wattage as indicated on the product.
- Switch the electricity back on at the fuse board. You may now switch on the light. Your non-electric shade is now ready for use.

Please retain this information leaflet for future reference

GENERAL INFORMATION

This fitting is designed for internal use only

Do not use polish or abrasive cleaner – just a soft dry cloth.

John Lewis Partnership 171 Victoria Street London SW1E 5NN www.johnlewis.com Issue 1 11/13

