Caring for your product	We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will damage the finish.	JOHN LEWIS & partners	LUCY DUO TOUCH LAMP USER GUIDE
Aftercare and Troubleshooting	If you experience any unresolvable technical issues with the product, contact your nearest John Lewis & Partners shop or John Lewis & Partner Technical Support on 03301 230106.		
Specification	Max. power: 2 x 28W Voltage: 220–240V, 50Hz IP rating: 20 Weight: 0.93g		
5 year guarantee	At John Lewis & Partners we test every light to high quality standards so we are able to offer you a 5 year guarantee.		
Recycling	This symbol X indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of		



Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.



John Lewis Partnership 171 Victoria Street London SW1E 5NN johnlewis.com

Made in China

Please retain these instructions for future reference.



Introduction	Please read the in	rchasing this Lucy Table Lamp. structions carefully before and satisfactory operation
Warnings	This is a Class II product a	nd must NOT be earthed.

This is a Class II product and must NOT be earthed. Z!Please read these instructions carefully before commencing any work. Your lamp has been packaged as separate parts to prevent damage during transit.


When manoeuvring or assembling this product, it must be lifted from the bottom section.

The lamp must be protected by a 3 amp fuse in the mains plug.

If you are in any doubt, please consult a qualified electrician.

For your safety, always switch off the supply before cleaning or adjusting.

If the mains cable becomes damaged it must only be replaced by a technically competent, qualified person.





Recommended bulb Recommended bulb (not included)

> 2 x 2-4W | FD. or 2 x 28W E14 Eco Golf

When changing a bulb, always switch off at the mains and allow the bulb to cool before handling. Dispose of used bulbs carefully. Do not exceed the rated power stated or use a different shape bulb from that indicated on the fitting.

Product assembly





Carefully unpack the carton, making sure all the parts are present before assembly.

Fit the shade (A) and secure in place with the shade ring (B).

Fit the recommended bulb per specifications.

Before plugging the lamp in, fit the recommended bulbs (C). If LED bulbs are used, they must be dimmable.

Plug into the mains and switch on by touching the metal base (D). Your table lamp is now ready for use. This product has a 3-stage touch dimmer: touch once to turn on, repeated touches will increase brightness, and the last touch to switch off.

