
Care instructions

Wipe clean with a damp cloth. Do not use abrasive cleaners.

Warnings!

The fittings pack contains small items which should be kept away from young children. Do not allow children to climb or play on this garment rail. Maximum load 40kgs. Do not exceed.





John Lewis Partnership 171 Victoria Street London SW1E 5NN johnlewis.com

Product Code:

57088024 57088043

Pre-assembly preparation

Thank you for purchasing this product. Please read the instructions and check pack contents carefully before starting assembly of this product. A full checklist of components is given in this leaflet. If any components are missing please contact John Lewis and partners customer services.

This product will take 1 person approximately 45 minutes to assemble.

The fitting pack contains small items which could present a choking hazard and should be KEPT AWAY FROM YOUNG CHILDREN.

Read this leaflet in full before commencing assembly.

Fittings and parts checklist

No.	Picture	Name	Qty	No.	Picture	Name	Qty
A		Top Frame	2	B		Lower Frame	2
G		Pole	1	D		Panel	1
9	0	Wooden Screw Knob	2	6		Screw	8
G	0	Washer	8	0	9	Screw Nut	8
0	<u> </u>	Wrench	1	0		Allen Key	1

Helpful advice before you begin

- 1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.
- 2. Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.
- 3. Assemble this product on a soft surface.
- To ensure an easier assembly, we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.
- 5. We recommend a periodic check on all fixing points to make sure they remain fully tightened.
- 6. Keep out of reach of small children. It contains small parts which might present a choking hazard.
- 7. Do not use any other tools other than those recommended to build this product.

Assembly instructions

