

Duhrer Round Table

Stock numbers

Thank you for purchasing this Duhrer Round Table. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product



This item is **HEAVY**



Necessary Tools



Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product.






Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.


This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.

This product is product takes approximately **45 MINUTES** TO assemble with **2 PEOPLE**.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.


Fittings and parts checklist

I	Top Panel x 1	A	Fixing Head x 4 pcs	
2	Leg Frame x 2	B	Fixing Dowel (64mm) x 4 pcs	
		C	Wooden Dowels (8 x 35) 8 pcs	
		D	Allen Key (M6) x 1 pc	
		E	Wedges x 1 pc	




Step by step assembly instructions


1. Insert 8x wooden dowels (C) into the holes by using a soft hammer first then screw 4x Fixing dowels (B) by using a screwdriver as shown. Repeat same step for the other leg frame (2).




2. Place the top panel (1) on a smooth surface carpet etc. Locate 4x Fixing heads (A) into the holes. Make sure that the holes on Fixing heads and the arrow should be aligned with the holes on the rails.





3. With the aid of an assistant, carefully attach leg frames (2) to the top panel carcass (1). Take care when locating tongue into leg groove. Secure the Fixing head connections by using Allen key provided as shown.




4. With the aid of an assistant, carefully turn the table on its feet. To install the extension leaf, release the clips on the underside of the table.



5. Open the table and take out the extension leaf as shown.



7. Locate the pins and close the table and re-lock the 4 metal locks.



8. The assembly is now complete.



Care and Maintenance

Wood Furniture

Wood displays different grain patterns depending on which way it is cut - for example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber - these are just characteristics of the natural beauty of wood. Some furniture is also deliberately aged and rustic.

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

How to care for your wood furniture

Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth. When using the surface for serving food and drinks it is best to use protective mats and coasters. Spillages should be wiped up as soon as possible.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time. Use of cleaning materials containing abrasive compounds, acidic or caustic reagents and any bleaches containing oxidising reagents should be avoided as prolonged use may damage the lacquer surface. Wipe up spills immediately. If sticky marks occur on the surface they can be removed with a dilute solution of warm soapy water. The offending area should be rubbed lightly and then completely dried immediately afterwards, before replacing any mats etc.

Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping.

Safety Instructions

Never drag furniture when moving it, always lift it. Please take care when handling or moving the furniture as careless handling may cause damage or injury. No liability will be accepted for damage or injury caused by incorrectly installed furniture.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

John Lewis Partnership 171 Victoria Street London SW1E 5NN
www.johnlewis.com