

## Recommended bulb

1 x 3.5W  
LED GU10

or

1 x 7W  
LED GU10

When changing a bulb, always switch off at the mains and allow the bulb to cool before handling. Dispose of used bulbs carefully. Do not exceed the wattage stated or use a different shape bulb from that indicated on the fitting.


## Specification

Maximum power: 7W  
Voltage: 240V, 50Hz  
IP Rating: IP20  
Weight: 0.85kg



Please keep these instructions for future reference.



This symbol  indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis do not operate instore take back, but as members of the Distributor Trade Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit [www.recycle-more.co.uk](http://www.recycle-more.co.uk).


We have taken great care to ensure that this product reaches you in perfect condition. However, should any parts be damaged or missing please contact our Product Helpline on (01202) 690945.

John Lewis Partnership  
171 Victoria Street  
London SW1E 5NN  
[johnlewis.com](http://johnlewis.com)

Made in China

John Lewis


User manual  
Charter  
Wall light



05/09/2018

Thank you for purchasing this Charter wall light. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.







### Warnings!

This is a Class II  product and must NOT be earthed.

Please read these instructions carefully before commencing any work.

This product is designed to be fixed to a wall and connected to a mains power outlet via the supplied 3-pin plug. **Do not remove the plug and connect by other means.**

### Parts list

Parts list	Image	Qty
Light fitting		1
Big screws		2
Wall plugs		2
Small screws		4
Retaining clips		2
Bulb tool		1

### Assembly

Please follow these instructions carefully. The installation of this product will be much easier with the help of an assistant.




Figure 1

#### Step 1

Select the mains power outlet you wish to connect the plug to and hold the product in place on the wall, marking the fixing hole positions. Check there are no mains cables or pipes beneath the wall. Drill the holes and fit the supplied wall plugs (1) - which are suitable for masonry only. **This product is not suitable for use in children's bedrooms.**




Figure 2

#### Step 2

Fix the product to the wall using the supplied screws (2).




Figure 3

#### Step 3

Fit the recommended bulb (3) as per the details overleaf.




Figure 4

#### Step 4

To keep the cable tidy, this product is supplied with two metal retaining clips. Decide on the cable position. Using the retaining clips as a template mark and drill the position of the fixing holes. Be careful not to damage any wiring or pipes. Place the clips around the cable and fix in place using the supplied fixing screws (4). **IMPORTANT: Children can become entangled in loose cable. Ensure excessive loops of cable are secured against the wall using the fittings supplied. Do not use this product in children's bedrooms.**

#### Step 5

Plug into a mains outlet. Your wall light is now ready for you. Switch on using the inline switch. The tilt of the head can be adjusted using the handle on the shade. **Note: Only use the handle to adjust as the shade can get hot.**

### Care Instructions

We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will damage the finish.