

Pre Lit Wreath – 766 88316

Thank you for purchasing this pre-lit battery operated Wreath. Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

Please Note

- FOR INDOOR USE ONLY.
- These lights use LEDs that are not replaceable.
- Requires 3 x AA batteries (not included).

Instructions for use

1. This product includes a try me function – please ensure when removing from the box you detach the try me connector from the battery box prior to use by following the wire from the try me button to the white connector on the battery box and firmly pulling on the white connector between your thumb and index finger – please also note that the try me button and connector cannot be disposed of in normal household waste. Please take it to your nearest collection facility
2. Carefully remove the product from the packaging.
3. The power switch is located on the battery compartment.

Changing the Batteries

To change the batteries remove the retaining screw in the battery compartment and take off the lid. Insert 3 x AA size batteries. Ensure the flat face (negative) end of the batteries align with the spring contacts within the battery compartment. Batteries should be removed and replaced by adults only.

- Use only recommended batteries or those of the same or equivalent type.
- Do not mix old and new batteries or batteries of a different type.
- Batteries are to be inserted with the correct polarity. The supply terminals are not to be short circuited.
- Always remove exhausted batteries from the product.
- Remove batteries if the set is not used for extended periods of time.
- Do not attempt to re-charge non rechargeable batteries.
- Rechargeable batteries are to be removed from the item before recharging. Rechargeable batteries are only to be charged under adult supervision.
- Batteries contain substances that may be harmful to the environment and human health.
- Keep out of reach of children and seek immediate medical help if swallowed.
- Never throw batteries in a fire or attempt to open the outer casing.

Warnings

- This product is a decoration not a toy. Keep out of reach of young children as may contain small parts that could represent a choking hazard.

CE – Complies with the RoHS Directive



This symbol indicates that batteries should not be disposed of in the normal household waste but taken to appropriate local recycling facilities, where and when these are available.



■ This symbol indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis do not operate in store take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk

If you have any issues regarding this product please contact 01462 744500

Please retain this information leaflet for future reference.