

Recommended bulb  
 1 x 5-7 Watt SES energy efficient LED (Candle)  
 or  
 1 x 28 Watt SES eco halogen (Candle)  
 (Bulbs not included)

Specification  
 Max power: 28W  
 Voltage: 220-240V, 50Hz  
 Net Weight: 1600g (each)



Please retain these instructions for future reference.


This symbol indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis does not operate instore take back, but as members of the Distributer Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit [www.recycle-more.co.uk](http://www.recycle-more.co.uk).

John Lewis partnership  
 171 Victoria Street  
 London SW1E 5NN  
 Johnlewis.com

Made in China

John Lewis

User manual  
 Delaney Duo Table Lamps



Thank you for purchasing these duo table lamps. Please read the instructions carefully before use to ensure safe and satisfactory operations of this product.

**Warning!**


To prevent electric shock, switch off the mains supply before maintaining this product.  
 Ensure other persons cannot restore electricity supply without your knowledge.  
 Always use correct bulb type with the correct wattage as indicated in the specification table. Never exceed the max power rating.  
 When changing a bulb always switch off at the mains first to allow the bulb to cool down before handling.  
 Dispose of used bulbs carefully.  
 The bulb and surrounding parts can become extremely hot during use.  
 The supply cord cannot be replaced. If the cord is damaged the product should be disposed of to avoid a safety hazard.  
 This product is Class II and shall not be earthed.  
 For indoor use only.

**Parts list**


	Parts list	Qty
A		1
B		1
C		1

**Assembly**


Carefully unpack the carton, make sure all parts are present before assembly.




**Step 1**  
 Your table lamps have been packaged with the lampshade upside down for safety, Unscrew the shade ring "C" to release the lampshade and fit the correct way up. Remove all packaging from the lampshade and replace the shade ring securely.



**Step 2**  
 Place the table lamps in the desired location ensuring that the cable will not present a trip or safety hazard. Insert the correct wattage bulb E14/SES (not supplied) into the lampholder, screw clockwise until firmly secured within the lampholder.



**Step 3**  
 Connect the plug to a convenient socket and turn on the power switch.



**Step 4**  
 To operate the table lamps, switch the inline switch for continues operation, and again to turn the lamp off.

**Care instructions**

We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will damage the finish.