


John Lewis

## User manual


### EVELYN SWING ARM FLOOR LAMP



Thank you for purchasing this Evelyn swing-arm floor lamp. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.

### Warnings!

- ❖ Always use the correct bulb type with the correct wattage as indicated in the specification table. Never exceed the Max. power rating. When changing a bulb always switch off at the mains first and allow the bulb to cool down before handling. Dispose of used bulbs carefully. The bulb and surrounding parts can become extremely hot during use.
- ❖ The supply cable runs through the inside of this product. Take care not to place undue stress on the cable whilst unpacking to prevent the possibility of a poor connection.
- ❖ If you are in any doubt consult a person competent to give advice on the assembly of electrical equipment.
- ❖ If the external flexible cable of the lamp is damaged it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- ❖ To prevent electrocution switch off at the mains supply before assembling or maintaining this fitting. Ensure the plug is not connected to any power supply and read instructions before assembly.
- ❖ **If moving the floor lamp always carry it from the base. Do not lift the floor lamp by the stem only as damage may occur**



## Assembly

Unpack the lamp and remove all packaging. Be careful not to scratch surfaces of the product whilst unpacking. Follow the diagram above for fixing detail.

Lay the product out on the floor. If the floor is not carpeted please cover it with a soft cloth to avoid damage to the flooring and surface of the product. Assembly should take place with the product lying flat.

1. Screw the **centre pole** onto the **upper lamp holder** section ensuring that the lamp holder section is kept still and that the pole is threaded on ensuring that the cable does not twist.
2. Screw the **lower pole** onto the **centre pole** ensuring that the centre pole is kept still and that the pole is threaded on ensuring that the cable does not twist.  
Gently pull any excess supply cable through the small hole in the base until it meets the pole assembly.
3. Turn the **base section** onto the other sections. Keep the poles parallel to avoid cross threading. Keep the **upper poles** stationary and only rotate the **base section**.
4. Attached the protective foam pad evenly to the bottom of the floor lamp base.

Stand the floor lamp upright and ensure all the assembled parts are fully tightened.

5. **To fit shade:** Remove the shade ring from lamp holder, fit the shade and replace shade ring to secure in place. Take care not to overtighten as this may cause damage to the fitting.
6. **Fit the bulb**, type and wattage as indicated on the fitting (bulb not supplied). **The wattage indicated must not be exceeded.**
7. Floor lamp is now ready for use.

### Care instructions

Wipe clean with a clean dry cloth, when product is switched off and has cooled down.

### Recommended bulb

1 x 42W E27 (ES) GLS eco halogen bulb

Or

1 x 12W energy saving spiral bulb

### Specifications

Max. Power: 60W

Voltage: 230V, 50Hz



Please retain these instructions for future reference.

John Lewis Partnership  
171 Victoria Street  
London SW1E 5NN  
[johnlewis.com](http://johnlewis.com)

Made in China  
Issue 1 10/17