

Recommended bulb

1 x 6W ES LED energy efficient classic clear bulb or
1 x 28W ES eco halogen classic bulb

Specifications

Max. power: 40W

Voltage: 220-240V, 50Hz

Dimensions: H158cm x W65cm x D55cm

Weight: 3.8kg



Please retain these instructions for future use

John Lewis

User manual

Jules

Marine head tripod floor lamp



John Lewis Partnership
171 Victoria Street
London SW1E 5NN
johnlewis.com


Made in China

Thank you for purchasing this Jules marine head tripod floor lamp. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.

Warnings!

To prevent electric shock, switch off the mains supply before maintaining this product. Ensure other persons cannot restore the electricity supply without your knowledge. Always use the correct bulb type with the correct power rating as indicated in the 'specifications' section.

Never exceed the max. power rating.



Assembly

Remove all protective packaging (Carton 1 and 2)

IMPORTANT NOTICE

Plastic/plastic bags can be dangerous. To avoid danger and Suffocation keep away from babies and children.

1. Place leg sections A and mounting section C on a firm surface.
2. Place the lamp with the feet of the legs together on a stable surface, ensure that the legs are evenly spaced to approx. 70-75cm apart.
3. Locate the stabilising arm E on the inside of each leg and raise to bring all 3 together so that the locating holes line up, and secure all 3 together with the bolt and wing nut provided attached to one of the arms.
4. Loosen mounting thumb screw D to allow the lamp head mounting pin to slot all the way down into the mount.
5. Supporting the lamp head with 2 hands guide the mounting pin down into the slot and secure with the thumb screw finger tight.
6. To insert the bulb, unclip the fastening F at the top of the lens section and open forwards.
7. The type and wattage of bulb can be found in the recommended bulb section, please do not exceed this.
8. Insert and screw the bulb clockwise into the lampholder without excessive force until finger tight.
9. Close the front section ensuring that the lip is on the outside of the lamp head all the way around and re-secure with clip F.

Care instructions

Ensure that the product has been switched off and allowed to cool, using a soft dry cloth

Wipe clean the outer surfaces only, do not wipe the bulb.

Before moving ensure the product is switched off and to avoid damage lift the item upright and by holding at least 2 legs close to the mounting section C.