Grayson two tier Coffee Table Stock number: 862 05402



Thank you for purchasing the Grayson two tier Coffee Table. Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

At John Lewis, we are committed to making great products possible.


From our in-house Design Team, to our Buyers, we work together to bring great design to life.

Our expert Product Technologists work collaboratively with our buyers and suppliers to ensure the legality, safety and quality of the product we sell.

We are are all committed to designing and developing products to the highest industry standards.

We hope you are happy with your product and welcome any feedback or comments you may have.

The John Lewis Team



05/10/18

Important safety information

Warnings


- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- △ Ensure the product is fully assembled as illustrated before use.


Do's


- ✓ Check the pack and make sure you have all the parts listed.
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with the ground at all times.


Don'ts


- X Do not over tighten screws or bolts.
- X Do not stand on the product.
- X Do not use power tools to construct as overtightening and panel failure may occur.
















05/10/18

Your table







Ref	Description	Dimensions	Qty
0	Тор	83cm × 70cm × 1.8cm	1
2	Shelf	66cm × 49cm × 1.8cm	1
3	Front leg	Dia. 5cm × 43cm	1
4	Shelf leg top	Dia. 5cm × 16cm	2
6	Shelf leg bottom	Dia. 4cm × 26cm	2

05/10/18 3


Product assembly
Grayson two tier Coffee Table
862 05402

Step 1 Parts, fittings and tools










Step 2
Parts, fittings and tools






Product assembly Grayson two tier Coffee Table


862 05402

Step 3
Parts, fittings and tools





Step 4
Parts, fittings and tools







PLEASE READ!

This veneered table top has a natural open grain finish. Please read the care guide thoroughly. We recommend using mats and wiping up spilled liquids. Avoid placing plant pots or vases without waterproof mats to prolong the life of this product.

5 05/10/18

Care and maintenance

Wood furniture

Wood displays displays different grain patterns depending on which way they are cut - for example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber - these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.

Wood veneers also allow a distinctive pattern to be created on some surfaces, such as tabletops and drawer fronts by the way slivers are arranged.

All timber and veneer surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

How to care for your wood furniture

Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.

Waxed furniture will need to be given a coat of beeswax a couple of times a year to help maintain its lustre. Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface when building up over time.

Make sure all surfaces are protected from the heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.

Our furniture will endure most temperatures in the home, but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by home heating can cause damage such as warping.

Wood furniture warning

Do not place very hot or very cold items on wood surface(s) unless adequately thick table mats are used to prevent such items from coming into contact with the wood.

Do not sit or stand upon wood surface(s)

Do not use the wood as a chopping surface. Do not strike the wood with hard or pointed items.

If the wood is chipped or broken stop using the product and consult the manufacturer or supplier.

Don not lean on or overload the doors or the handles. Excessive force may result in damage to the unit.

Retain these instructions for future reference.

Your feedback is very important to us and we would love to hear your comments on your new furniture. Please visit our website to leave a review. Thank you.

John Lewis Partnership 171 Victoria Street London SW1E 5NN johnlewis.com

05/10/18

6