

Light Source

Integrated LED

25 x 0.06 Watt Energy Efficient LED Bulbs (non replaceable)

Specification

Max Power: 1.5W

Voltage: 3.7V

Power Source: 1 x 18650 Li Rechargeable 1200 mAh Battery (included) / Solar Panel (included)

IP Rating: 44

Lumens: 40

Net Weight: 1.25 Kgs


Quality Guaranteed

At John Lewis & Partners we test every light to high quality standards, so we can offer a 2-year guarantee.

Recycling

Please retain these instructions for future reference.



This symbol  indicates that this product should not be treated as normal house-hold waste and it should be recycled. John Lewis does not operate in store take back, but as members of the Distributer Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.


We have taken great care to ensure that this product reaches you in perfect condition. However, should any parts be damaged or missing please contact the customer service team on 03456 050 144.

John Lewis Partnership
171 Victoria Street
London SW1E 5NN
Johnlewis.com

Made in China



RATTAN OUTDOOR LANTERN SMALL NATURAL USER GUIDE



Thank you for purchasing this Rattan Outdoor Lantern Small Natural. Please read the instructions carefully before use to ensure safe and satisfactory operations of this product.

Charging and Operation


Before using the light set for the first time, we would recommend you charge the product for 2 full days (turning off at dusk).

Warnings


This product is for temporary outdoor use.

Do not connect the lantern electrically to any other light set.

If required, only replace the rechargeable battery with the recommended type supplied (1 x 3.7V 18650 Li Rechargeable 1200 mAh Battery).

This symbol  indicates that batteries should not be disposed of in the normal household waste, but taken to appropriate local recycling facilities, where and when these are available. Never throw batteries in a fire or attempt to open the outer casing.

Parts List



Care instructions

We recommend cleaning with a soft, dry cloth. Do not use abrasive materials, as these will damage the finish.

Assembly

Please ensure you remove all packaging from the product before positioning outside. Carefully cut off the cable tie around the solar panel. Peel off the protective film that is covering the solar panel and remove the protective covers from the feet.

1. Position the lantern in direct sunlight and where it will be exposed for the longest time. Do not position the lantern where there are shadows from buildings, trees or other foliage, as this will reduce the charging performance.
2. Push the switch down on the top of the solar panel "B" for continuous operation. The lights will automatically switch on at dusk and recharge during the day.
3. To replace the battery, you can access the battery box on the bottom of the solar panel. You will need a small phillips screw driver. First, remove two screws from the underside of the solar panel. Separate, then unscrew the remaining screws on the separated panel. (see diagram)
4. Only replace the rechargeable battery with the recommended type: 1 x 3.7V 18650 Li Rechargeable 1200 mAh battery. Securely re-screw all screws back into their housings.

Full charge will last up to 6-8 hours per day.

