


ANSEL WALL LIGHTUSER GUIDE





Introduction

Thank you for purchasing this **Ansel wall light**. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.

Warnings



We recommend a qualified electrician carries out any electrical wiring. For your safety, this product must be installed in accordance with local Building Regulations.

If in any doubt, or where required by the law, consult a competent person who is registered with an electrical self-certification scheme. Further information is available online or phone your Local Authority.

To prevent electric shock, switch off the mains supply before installing or maintaining this product. Ensure other persons cannot restore the electricity supply without your knowledge.

Always use the correct bulb type with the correct wattage as indicated in the specification table.

When changing the bulb, always switch off at the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

Caution! The bulb and surrounding parts can become hot during use.


To reduce the risk of strangulation the flexible wiring connected to this luminaire shall be effectively fixed to the wall if it is mounted within arm's reach.

Parts list	Description	Image	Quantity	
	A Light fitting	 	1	
	B Fixings	44 11	2	
	C Shade		1	
	D Shade ring		1	

Product assembly

1






Using the mounting bracket/back plate (A) as a template, mark and drill fixing holes in the wall. Ensure the holes are drilled into a solid wall or other suitable mounting and not just into plaster. Secure the mounting bracket/back plate to the surface using suitable fixings for the type of material (B)

2





Fit the shade (C) by first removing the shade ring (D) already attached to the lamp holder section. Position the shade over the lampholder and refit the shade ring to secure in place. Take care not to over-tighten as may cause damage to the fitting.

Fit bulb: type and wattage as indicated on fitting. **The**

wattage indicated must not be exceeded.

3



Plug the wall lamp into the wall socket and switch on. You wall lamp is now ready for use.

Caring for your product

We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will damage the finish.

Replace bulb from John Lewis or established brand of the same type and compatibility.

Aftercare and Troubleshooting

If you experience any unresolvable technical issues with the product, contact your nearest John Lewis & Partners shop or John Lewis & Partner Technical Support on 03301 230106.

Why is the light not working when switched on? Check your power supply is switched on Turn off light and check that the bulb is inserted correctly Check the bulb is still in working order.

Specification

Max. power: 28W or 5-7W LED (400-700 lumen)

Voltage: 220-240V, 50Hz IP rating: 20

Weight: 0.6kg



5 year guarantee

At John Lewis & Partners we test every light to high quality standards so we are able to offer you a 5 year guarantee.

Recycling

This symbol indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.



John Lewis Partnership 171 Victoria Street London SW1E 5NN johnlewis.com

Made in China

Please retain these instructions for future reference.