

Elliott Task Lamp

706 61705 Black 706 61706 White 706 61707 Quince 706 61708 Slate 706 61709 Chrome

Thank you for purchasing this Elliott Task Lamp. Please read the instructions and warnings carefully before assemble of this products to ensure safe and satisfactory operation .

Warnings!


- The product is Class II.
- This lamp is for indoor use only.
- 240V~50Hz
- Always use the correct type and wattage bulb (E27 Max 60W or 15W Energy Saver); Do not exceed the wattage stated.
- When changing a bulb, ensure the product is unplugged and always allow the old bulb to cool down before handling, Dispose of used bulb carefully.
- If the external flexible cable cord were damaged; the product should be destroyed in order to avoid safety hazard.

Assembly instructions:

1. Carefully unpack the carton, make sure all parts were included (see the drawing) before assembly.
2. Place lamp parts on a flat surface as per sketch.
3. Attach lamp body (C) to the Lamp base (A) and tighten with the screw (B).
4. Attach the correct type and wattage bulb to the socket (bulb were not included), Insert the plug into the power supply, turn on the switch.

Care and cleaning

We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will damage the finish.



Please retain this information leaflet for future reference.

John Lewis Partnership 171 Victoria Street London SW1E 5NN
www.johnlewis.com