Lasko single bed

## Instruction manual

Important
Retain for future reference
Please read carefully

John Lewis

Thank you for purchasing this Lasko single bed. Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

Your child's safety is your responsibility. If you have a query with this product or require replacement parts, please contact your nearest John Lewis department store.

Lay out the parts on a soft level surface and compare to the part/fixings checklist below. Do not discard any packaging until you are sure that you have all the parts.

Ensure that your child is kept clear during assembly due to small parts.

This product complies with BS EN 8509:2008.

Fixings

1.

Connecting bolt × 8

2.

Nut × 8

3.

Washer × 8

4.

Dowels × 8

5.

Screws × 12

Parts

A.

Headend × 1

B.

Footend × 1

C.

Side rail × 2

D.

Slatted base × 1

You will need:

1 × cross head screwdriver

1 × spanner (supplied)

Step 1

Fixing 1 × 8 pieces

Part A

Part B

Screw by hand eight connecting bolts (fixing 1) into the nuts in the head end (part A) and foot end (part B).

Step 2

Fixing 4 × 8 pieces

Part C × 2

Insert the eight dowels (fixing 4) into the middle holes in the side rails (part C).

Step 3

Fixing 2 × 8 pieces   Fixing 3 × 8 pieces

Part A

Fixing 2

Fixing 3

Part C × 2

Part B

Connect together the head end (part A) and side rail (part C). See picture above. Align correctly the washer (fixing 3) and screw with nut (fixing 2). Tighten using supplied spanner. Now, repeat the step with the foot end (part B).

Step 4

Fixing 5 × 12 pieces

Place the slatted base (part D) onto the brackets on the side rails. Secure the slats with the twelve screws (fixing 5) using a crosshead screwdriver.

Care and maintenance

Your furniture may be cleaned by wiping with a damp cloth and drying with a soft clean cloth.

Do not use abrasives, bleach, alcohol or ammonia-based household polishes.

Take care when handling or moving the furniture. Careless handling may cause damage.

Wood Furniture

Wood displays different grain patterns depending on which way they cut - for example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber - these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.

Wood veneers also allow distinctive patterns to be created on flat surfaces, such as table tops and drawer fronts by the way the slivers are arranged.

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

Safety notes

For children aged 4 years and above.

WARNING! Do not place this child's bed near heat sources, windows and other furniture.

WARNING! Do not use this child's bed if any part is broken, torn or missing.

The mattress should be no more than 30mm shorter or narrower than the internal length or width of the bed. Suitable for use with mattress of 1900mm in length, 900mm in width and a maximum thickness of 200mm.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person.

All assembly fixings should always be tightened properly. Periodically check all fixings to ensure none have come loose and that there is no risk of clothing or parts of the body becoming snagged or trapped.

Do not allow your child to jump on the bed. This may result in damage to the furniture and/or injury to your child.

The bed should be placed either tight against a wall or a minimum gap of 300mm should be left between the wall and the bed to avoid danger of suffocation.

Keep children clear during assembly as pack contains small parts which may present a choking hazard.

Be aware of the risk of open fires and other such sources of strong heat, such as electric bar fires, gas fires, etc. in the vicinity of the bed.

Please do not discard any packaging until you are sure that you have all the parts.

Please retain this information leaflet for future reference.