


# Array Cabinet

Stock Number: 862 55001  
862 55002  
862 55003  
862 99101



L92 W40 H75cm

Thank you for purchasing the Array Cabinet. Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

At John Lewis, we are committed to making great products possible.

From our in-house Design Team, to our Buyers, we work together to bring great design to life.


Our expert Product Technologists work collaboratively with our buyers and suppliers to assure the legality, safety and quality of the product we sell.

We are all committed to designing and developing products to the highest industry standards.


We hope you are happy with your product and welcome any feedback or comments you may have.

The John Lewis Team

**Tools required**




(Not Supplied)



(Supplied)

Time to assemble 30 Minutes

**People to assemble**



# Important safety information

## Warnings







- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- ⚠ Ensure the product is fully assembled as illustrated before use.

## Do's

- ✓ Check the pack and make sure you have all the parts listed.
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with ground at all times.

## Don'ts


- ✗ Do not over tighten screws or bolts.
- ✗ Do not stand on the product.
- ✗ Do not use power tools to construct as overtightening and panel failure may occur.








# Array Cabinet

Stock Number: 862 55001 / 862 55002 / 862 55003 / 862 99101

## Fixtures and Fittings Supplied



## Fixtures and Fittings Supplied (actual size)

Ref	Description	Dimensions	Qty.	
A	Screw	5x15 mm	2	
B	Anti Tip	15x70 mm	2	
C	Allen Key	4x70 mm	1	
D	Shelf Pin	5x16 mm	4	

Shelf Size : W 35 X L 71 cm

# Assembly:-

## Array Cabinet

Stock Number: 862 55001 / 862 55002 / 862 55003 / 862 99101

### Step 1


Parts, Fittings & tools



(Not Supplied)

In order to prevent tipping or overturning we recommend use of the wall attachment fitting provided


Measure the distance between the cut at slots on the back of your cabinet and make the position as your wall accordingly




### Step 2

Parts, Fittings & tools

**B**




The bracket will pass through the slots in the back panel.



## Step 3


Parts, Fittings & tools



Screw the bracket to the cabinet using the pre-drilled hole with screw provided


## Step 4

Parts, Fittings & tools




# Step 5

Parts, Fittings & tools



# Step 6


Parts, Fittings & tools



# Hinge Adjustment Instructions


## 1- Sideways Adjustments.-

This adjustment system allows the door to be moved sideways without changing the gap behind the door. Adjust the screw (A) in or out until the door is aligned to satisfaction:




## 2- Height Adjustment -

Partially unscrew (B) which will allow you to adjust the height of the door. Once in place, retighten screw (B). Optionally, the adjustment cam (C) on the mounting plate can be used for aligning the door height.



## 3- Depth Adjustment -

Adjust the distance between the door and the side of the cabinet by turning the adjustment cam (D). Turn counter clockwise to increase the distance and clockwise to decrease the distance.






## Assembly:-

# Array Cabinet


Stock Number: 862 55001 / 862 55002 / 862 55003 / 862 99101

## Handle Adjustable & Adjustable Foot Instruction



Place the Product upside down and place the handle.(2) on the matching holes. Tighten with Allen bolt with the help of Allen Key. Repeat the same procedure for second handle

# Ready to Use



Wall attached item only:


## A guide to wall mounting and fixings

### **Warning**

Wall fixing screws are not included, since different wall materials require different type of screws / fixings. Please ensure you use the correct screws / fixings for your type of walls and seek professional advice if you are not sure.


Failure of the product due to incorrect fixings is the responsibility of the installer.

**Important:** When drilling into the walls always check that there are no hidden wires or pipes etc.




#### **Types of walls**

You can use one of the following types of wall plug if your walls are made of brick, breezeblock, concrete, stone or wood.




#### **1. General Purpose wall plug**

Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.




#### **2. Plasterboard wall plug**

For use when attaching light loads on to plasterboard partitions.




#### **3. Cavity fixing wall plug**

For use with plasterboard partition or hollow wooden doors.



#### **4. Cavity fixing – heavy duty wall plug**

For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.



#### **5. Hammer fixing wall plug**

For use with wall stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

#### **6. Shield Anchor wall plug-Heavy loads**

For use with heavier loads such as TV and Hi-Fi speakers and satellite dishes etc.



#### **Care and maintenance**

**Safety:** Periodically check all fittings and wall fixings to ensure they have not come loose and retighten as necessary.

## Care guide

### Care and maintenance

#### Wood furniture

Wood displays different grain patterns depending on which way it is cut – for example, the ‘medullary ray’ which can appear on oak furniture is a mark of good quality timber – these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.

Wood veneers also allows a distinctive pattern to be created on some surfaces, such as tabletops and drawer fronts by the way slivers are arranged.

All timber and veneer surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

#### How to care for your wood furniture

Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.

Spray polishes are best avoided as they contain silicones which may spoil the furniture’s surface when building up over time.

Make sure all surfaces are protected from heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.

Our furniture will endure most temperatures in the home, but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by home heating can cause damage such as warping.

#### Safety instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and retighten when necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person.

No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

Do not place weight too close edge of the table and do not lean on it .

Retain these instructions for future reference.

**Your feedback is very important to us and we would love to hear your comments on your new furniture.**

**Please visit our website to leave a review. Thank you.**

John Lewis Partnership

171 Victoria Street

London SVV1E 5NN

[www.johnlewis.com](http://www.johnlewis.com)