


Elementary changing table

Stock number: 324 30602/324 30603



IMPORTANT RETAIN FOR FUTURE REFERENCE READ CAREFULLY
H101 W 86 D 55cm

Introduction Thank you for purchasing this Elementary changing table.


Please read the instructions carefully before

use to ensure safe and satisfactory operation of this product.

Recommended changing mat: 820mm x 500mm,

This changing unit complies with BS EN 12221-1/2:2008 + A1: 2013.

Tools required



Important safety information

△ Warning: In order to prevent overturning, this product must be used with the wall attachment device provided.

Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent topple over, please observe the following:

- 1. Use the wall attachment device provided
- 2. Never allow children to climb or hang on drawers, doors or shelves.
- 3. Place heaviest items in the lower drawers or shelves.

An attachment device is provided with your product; however, you will need to source suitable fixings for your wall type. If in doubt, please consult a qualified tradesperson.

Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.

Warnings


- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- \triangle Ensure the product is fully assembled as illustrated before use.
- ⚠ Care should be taken that no screws are loose because a child could trap parts of their body, or clothing (e.g. strings, necklaces, ribbons, dummies, etc) which could pose a risk of strangulation.
- ⚠ Ensure that the wall bracket is used to securely attach the change table to the wall to prevent tipping.
- \triangle Any additional or replacement parts must only be obtained from John Lewis & Partners.
- △ During assembly children should be kept away from the product due to possible risk of injury.
- ⚠ Do not use this item if any components are missing or damaged.


Do's


- ✔ Check the pack and make sure you have all the parts listed.
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with the ground at all times.


Don'ts


- **X** Do not over tighten screws or bolts.
- **X** Do not stand on the product.
- ✗ Do not use power tools to construct as over tightening and panel failure may occur.















Your changing table




Ref	Description	Dimensions	Qty
1	Top panel	860mm × 508mm × 18mm	1
2	Changer back	420mm × 70mm × 19mm	1
3	L/R side panel	1010mm × 780mm × 21mm	2
4	Crossbar	508mm × 60mm × 19mm	2
6	Bottom panel	750mm × 508mm × 38mm	1

Internal dimensions

Stock number : 324 30602

Overall size: H101 W 86 D 55cm

Fixtures and fittings




	s and fittings d (actual size)	mm 0 10 20 30 40 50 60 70		
Ref	Description	Dimensions	Qty	
A	Wooden dowels	8mm × 30mm	12	
В	Screw	3.5mm × 16mm	1	Omm>
9	Allen head screw	6mm × 30mm	2	
O	Allen head screw	6mm × 60mm	8	
(3	Barrel nut	10mm x 15mm	8	

Fixtures and fittings supplied (not actual size)

Ref	Description	Dimensions	Qty	
•	Allen key M4	M4 × 106mm	1	
G	Metal 'L' Bracket		1	


Product assembly Elementary changing table





Product assembly Elementary changing table

Step 3


Parts, fittings and tools







The Metal "L" Bracket (G) can be installed on part 4(Crossbar) or part 3 (L/R side panel)




The Metal "L" Bracket (G) can be installed on part 4(Crossbar) or part 3 (L/R side panel)


Step 8
Parts, fittings and tools

Product assembly Elementary changing table

Step 9

Parts, fittings and tools







Product assembly Elementary changing table


Wall mounting and fixings


 \triangle Warning In order to prevent overturning this product must be used with the wall attachment device provided. Wall fixing screws are not included, since different wall materials require different types of screws/ fixings. Please ensure you use the correct screws/fixings for your type of walls and seek professional advice if you are not sure. Installation shall be carried out exactly according to the instructions provided - otherwise a safety risk can occur if incorrectly installed. Failure of the product due to incorrect fixings is the responsibility of the installer.


Important: When drilling into the walls always check that there are no hidden wires or pipes etc.














Types of walls

You can use one of the following types of wall plug if your walls are made of brick, breezeblock, concrete, stone or wood.

1. General Purpose wall plug

Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

2. Plasterboard wall plug

For use when attaching light loads on to plasterboard partitions.

3. Cavity Fixing wall plug

For use with plasterboard partitions or hollow wooden doors.

4. Cavity Fixing- Heavy Duty wall plug

For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

5. Hammer Fixing wall plug

For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

6. Shield Anchor wall plug - Heavy loads

For use with heavier loads such as 1V and Hi-Fi speakers and satellite dishes etc.

Safety: Periodically check all fittings and wall fixings to ensure they have not come loose and retighten as necessary.

Care and maintenance

Your furniture may be cleaned by wiping with a damp cloth and drying with a soft clean cloth.

Do not use abrasives, bleach, alcohol or ammonia-based household polishes.

Take care when handling or moving the furniture. Careless handling may cause damage.

Regularly check that all fixings are tightened and that there are no broken or damaged parts.

Safety notes

Warning: Do not leave your child unattended.

Keep children clear during assembly as pack contains small parts which may present a choking hazard.

All assembly fixings should always be tightened properly. Care should be taken that no screws are loose because a child could trap parts of their body, or clothing (e.g. strings, necklaces, ribbons, dummies, etc) which could pose a risk of strangulation.

The changing area is suitable for use up to 12 months old or 11kg in weight.

When using a changing mat, ensure the changing mat does not compromise the elective height of the changer barriers.

Be aware of the risks of open fires and other such sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the dresser.

Ensure that the wall bracket is used to securely attach the changing table to the wall to prevent tipping.

Do not use the changing unit if any of the parts are broken, torn or missing.

Any additional or replacement parts can only be obtained from the manufacturer or the distributer.

Safety instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and retighten when necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person.

No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

Retain these instructions for future reference.

Your feedback is very important to us and we would love to hear your comments on your new furniture. Please visit our website to leave a review. Thank you.