

ABACUS 3 Drawer wide chest

Stock Number 22304



Step By Step Assembly Instructions

PRE-ASSEMBLY PREPARATION


Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact your nearest stockist.

This product takes approximately **40 MINUTES** to assemble with **2 People**.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.







Read this leaflet in full before commencing assembly.

You will require a crosshead screwdriver.



Panel and Fittings Identification


Item	Description	Qty.	Item	Description	Qty.	Item	Description	Qty.
1	LEFT side panel	1	2	RIGHT side panel	1	3	Top	1
4	Base	1	5	Back panel	1	6	Legs	4
7	Drawer front A	1	8	LEFT drawer side A	1	9	RIGHT drawer side A	1
10	Drawer back A	1	11	Drawer bottom	3	12	Rails	3
13	Drawer front B	1	14	LEFT drawer side B	1	15	RIGHT drawer side B	1
16	Drawer back B	1	17	Drawer front C	1	18	LEFT drawer side C	1
19	RIGHT drawer side C	1	20	Drawer back C	1	A	File hanging rods	4
B	Screws 60mm	4	C	Dowels 25mm	12	D	Screws 35mm	12
E	Screws 80mm	4	F	Plastic back holders	4	G	Allen key	1
H	Camlocks Ø12; 10mm	12	I	Plastic buffers	3	J	Screws 10mm	12

Item	Description	Qty.	Item	Description	Qty.	Item	Description	Qty.
K	Dowels 35mm	12	L	Camlocks Ø15;13mm	4	M	Connecting bolts	16
								
N	Glue	1	O	Screws 30mm	3	P	Runners	6
								

Step 1

Fittings


Take the left (1) and right (2) side panel.
Insert the twelve dowels (K) into the holes provided.
Insert the four camlocks (L) into the holes provided in the side panel (1,2) inner faces.



Step ②

Screw the six runners (P) into the predrilled holes in the side panels (1, 2) using screws (J). Tighten using the crosshead screwdriver.

Fittings




Step ③

Take the top (3) and lay it on a flat and clean surface with the predrilled holes uppermost.


Screw the four connecting bolts (M). Tighten using the crosshead screwdriver.

Fittings




Step ④

Locate the left side (1) onto the top (3) as shown in the picture.
Tighten the two camlocks (L) using the crosshead screwdriver.




Step ⑤

Locate the right side (2) onto the top (3) as shown in the picture.
Tighten the two camlocks (L) using the crosshead screwdriver.



Step ⑥

Place the back panel (5) into the grooves.




Step ⑦

Locate the base (4) onto the sides (1, 2) and back panel (5) as shown in the picture.

Fittings


Tighten the four screws (B) using the allen key (G).



Step ⑧

Attach the four legs (6) using one screw (E) per leg. Tighten the screw (E) using the allen key (G).


Fittings



E x 4




G x 1




Step ⑨

Turn the carcass of the chest onto its legs. Do not pivot or pull, otherwise the legs might crack. Always lift the unit from the base when moving it, do not drag along the ground, as this may damage the legs. It is recommended that two people should move the unit, never move it alone.




Step 10

Fittings



F x 4

Insert the four plastic back holders (F) into the grooves in the top (3) and the base (4). Screw the four plastic back holders (H). Tighten using the crosshead screwdriver.




Step 11

Fittings



M x 12

Take the drawer front A (7), drawer front B (13) and drawer front C (17). Screw the twelve connecting bolts (M) into the drawer fronts. Tighten using the crosshead screwdriver.




Step 12

Take the rail (12).
Insert the four dowels (C) into the holes provided.

Fittings




C x 4




Step 13

Locate the drawer sides A (8, 9) onto the drawer back A (10).
Attach the drawer sides A (8, 9) using four screws (D). Tighten using the crosshead screwdriver.

Fittings




D x 4



Step 14

Slide the drawer bottom (11) in the groove in the drawer sides A (8, 9) and push into the drawer back A (10).




Step 15

Locate the rail (12) as shown in the picture.
Screw the one screw (O). Tighten using the crosshead screwdriver.

Fittings




O x 1




Step 16

Take the drawer front A (7).
Put a few drops of glue (N) into the two holes.

Fittings



N x 1




Step 17

Fittings



H x 4


Locate the drawer front A (7) onto the drawer sides A (8, 9) and the rail (12).
Insert the four camlocks (H) into the holes provided in the drawer sides A (8, 9) as shown in the picture. Tighten the four camlocks (H) using the crosshead screwdriver.




Step 18

Fittings

Locate the drawer sides B (14, 15) onto the drawer back B (16). Attach the drawer sides B (14, 15) using four screws (D). Tighten using the crosshead screwdriver.




D x 4



Step 19

Slide the drawer bottom (11) into the groove in the drawer sides B (14, 15) and push into the drawer back B (16).




Step 20

Locate the rail (12) as shown in the picture.
Screw the one screw (O). Tighten using the crosshead screwdriver.

Fittings




O x 1




Step 21

Take the drawer front B(13).
Put a few drops of glue (N) into the two holes.

Fittings



N x 1



Step 22


Fittings



H x 4

Locate the drawer front B (13) onto the drawer sides B (14, 15) and the rail (12).

Insert the four camlocks (H) into the holes provided in the drawer sides B (14, 15) as shown in the picture. Tighten the four camlocks (H) using the crosshead screwdriver.



Step 23


Fittings



H x 4


Locate the drawer sides C (18, 19) onto the drawer front C (17).

Insert the four camlocks (H) into the holes provided in the drawer sides C (18, 19) as shown in the picture. Tighten the four camlocks (H) using the crosshead screwdriver.



Step 24


Slide the drawer bottom (11) into the groove in the drawer sides C (18, 19) and push into the drawer front C (17).




Step 25

Put a few drops of glue (N) into the two holes.

Fittings




N x 1



Step 26



Locate the rail (12) onto drawer front C (17).



Step 27


Insert the four file hanging rods (A) into the predrilled holes in the drawer front C (17) as shown in the picture.

Fittings



Step 28

Fittings




D x 4



O x 1

Locate the drawer back C (20) onto the drawer sides C (18, 19) and rail (12). Be sure that the file hanging rods (A) are correctly inserted into the holes provided in the drawer front C (17).

Attach the drawer back C (20) using the four screws (D) and the one screw (O). Tighten using the crosshead screwdriver.




Step 29

Fittings



I x 1

Stick the plastic buffers (I) onto drawer front C(17) as shown in the picture.




Step 30

Stick the plastic buffers (I) onto drawer front B (13) as shown in the picture.

Fittings



1 x 1




Step 31

Stick the plastic buffers (I) onto drawer front A (7) as shown in the picture.

Fittings




1 x 1




Step 32

Insert the drawers as shown in the picture.
The assembly is now complete.




WARNING

Always lift the unit from the base when moving it, do not drag along the ground, as this may damage the legs. It is recommended that two people should move the unit, never move it alone.



NEVER DRAG UNIT ALONG THE GROUND



**ALWAYS LIFT THE UNIT FROM
THE BASE WHEN MOVING**