


# Montreal Wardrobe

Wardrobe

Stock Number : 80317609

Thank you for purchasing this Montreal Wardrobe. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



For product support or spare parts please call the John Lewis Helpline;


T: 01244 689949

E: [mail@fwgroup-uk.com](mailto:mail@fwgroup-uk.com)

## PRE-ASSEMBLY PREPARATION

Please ensure instructions are read in full before attempting to assemble this product

### Necessary Tools



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the John Lewis helpline.

This product is **HEAVY**. It should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.

This product takes approximately **60 MINUTES** to assemble with **2 PEOPLE**.
















The fittings pack contains **SMALL PARTS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.

If you require any additional information or have any issues with this product please call the John Lewis Helpline on 01244 689949 or email:[mail@fwgroup-uk.com](mailto:mail@fwgroup-uk.com)

# Fittings and parts checklist


## Fittings

A	LARGE CAMFIX x20		H		M4 x 25mm SCREW x12
B	SMALL CAMFIX x4		I		M4 x 32mm SCREW x2
C	LARGE MINIFIX x24		J		M4 x 50mm SCREW x2
D	M6 x 30mm DOWEL x4		K		RING HOLDER ( 6/8" x 19mm ) x2
E	M8 x 30mm DOWEL x14		L		CHROME PIPE ( 6/8" x 817mm ) x1
F	M3.5 x 16mm PAN HEAD SCREW x14		M		7/8" HINGES x6
G	M3.5 x 16mm SCREW x24		N		FLAT WASHER M6 x2
			O		STRAP x2

## Parts

NO	DESCRIPTION	QTY
1	SIDE PANEL RIGHT	x 1
2	SIDE PANEL LEFT	x 1
3	TOP PANEL	x 1
4	DOOR LEFT & RIGHT	x 2
5	BOTTOM PANEL	x 1
6	DRAWER HEAD	x 1
7	DRAWER BACK	x 1
8	DRAWER SIDE PANEL LEFT & RIGHT	x 2
9	DRAWER PLY	x 1
10	DRAWER BOTTOM RAIL	x 1
11	BOTTOM RAIL FRONT	x 1
12	BOTTOM RAIL BACK	x 1
13	BACK PLY SUPPORT	x 2
14	BACK PLY	x 3
15	TOP & BOTTOM PANEL HRAIL	x 2

Key diagram



# Pre-assembly Preparation

1

C X 10

K X 1

FX 3

Insert the Large Minifixs (C) into the pre-drilled holes on the Side Panel Right (1) as shown in the diagram. Attach the Ring Holder (K) to the Side Panel Right (1) into the pre-drilled holes, securing by using a screwdriver to tighten the M3.5 x 16mm Pan Head Screws (F) as shown in the diagram.

2

C X 10

K X 1

FX 3

Insert the Large Minifixs (C) into the pre-drilled holes on the Side Panel Left (2) as shown in the diagram. Attach the Ring Holder (K) to the Side Panel Left (2) into the pre-drilled holes, securing by using a screwdriver to tighten the M3.5 x 16mm Pan Head Screws (F) as shown in the diagram.

3

EX 2

Insert the Wood Dowels (E) into the pre-drilled holes on the Bottom Back Hrail (12) as shown in the diagram.

4


DX 4


Insert the Wood Dowels (D) into the pre-drilled holes on the Drawer Back (7) as shown in the diagram.

# Pre-assembly Preparation


5  C X 4

Insert the Large Minifixs (C) into the pre-drilled holes on the Drawer Head (6) as shown in the diagram.




6  E X 6  
 H X 3

Insert the M8 x 30mm Dowels (E) into the pre-drilled holes on the Top Panel Hrail (15) and Top Panel (3) as detailed in the diagram. Attach the Top Panel Hrail (15) to the Top Panel (3) and secure in place using M4 x 25mm Screws (H) as shown in the diagram.




7  E X 6  
 H X 3

Insert the M8 x 30mm Dowels (E) into the pre-drilled holes on the Bottom Panel Hrail (15) and Bottom Panel (5) as detailed in the diagram. Attach the Bottom Panel Hrail (15) to the Bottom Panel (5) and secure in place using M4 x 25mm Screws (H) as shown in the diagram.



8  G X 12  
 M X 6


Insert the Hinges (M) to the Doors (4) and secure in place using M3.5 x 16mm Screws (G) as shown in the diagram.



## Step by step assembly instructions


### Step One

Attach the Drawer Side Panels (8) to the Drawer Head (6) by pushing the pre-attached Large Minifixs (C) into the pre-drilled holes, securing in place by using a screwdriver to tighten the Small Camfixs (B) as shown in the diagram. Next attach the Drawer Bottom Rail (10) to the Drawer Head (6) by pushing into the pre-drilled holes as detailed below.




### Step Two

Attach the Drawer Back (7) to the Drawer Side Panels (8) by pushing the pre-attached Wood Dowels (D) into the pre-drilled holes, securing in place by using a screwdriver to tighten the M4 x 32mm Screws (I) as shown in the diagram. Next attach Drawer Back (7) to the Drawer Ply (9) and Drawer Bottom Rail (10) by pushing into the pre-drilled hole as detailed below.




## Step Three

Attach the Top Panel (3) and Bottom Panel (5) and Bottom Back Rail (12) to the Side Panel Left (2) by pushing the pre-attached Large Minifixs (C) and Wood Dowels (E) into the pre-drilled holes, securing in place by using a screwdriver to tighten the Small Camfixs (A) as shown in the diagram. Next attach the Bottom Front Rail (11) and Back Ply Supports (13) to the Side Panel Left (2) by pushing the pre-attached Large Minifixs (C) into the pre-drilled holes using a screwdriver to tighten the Small Camfixs (A) as shown in the diagram.




## Step Four

Place in the Back Plys (14) into the gap of the Top Panel (3) and the Side Panel Left (2) and the Back Ply Supports (13) as detailed in the diagram. Then Place in the Chrome Pipe (L) into the Ring Holder (K) as shown in the diagram.




## Step Five

Attach the Side Panel Right (1) to the Top Panel (3) and Bottom Panel (5) and Bottom Back Rail (12) by pushing the pre-attached Large Minifixs (C) and Wood Dowels (E) into the pre-drilled holes, securing in place by using a screwdriver to tighten the Small Camfixs (A) as shown in the diagram. Next attach the Side Panel Right (1) to the Bottom Front Rail (11) and Back Ply Supports (13) by pushing the pre-attached Large Minifixs (C) into the pre-drilled holes, securing in place by using a screwdriver to tighten the Small Camfixs (A) as shown in the diagram.



## Step Six

Attach the M4 x 50mm Screws (J) into the pre-drilled holes on the Bottom Front Rail (11) secure by a screwdriver to tighten as shown in the diagram.






---

## Step Seven


Attach the Doors (4) to the Side Panel Right (1) and Side Panel Left (2), securing in place by using a screwdriver to tighten the M3.5 x 16mm Screws (G) to the Hinges (M) as shown in the diagram.



---


## Step Eight

Insert the M4 x 25mm Screws (H) and M3.5 x 16mm Pan Head Screws (F) into the pre-drilled holes at the Back of the Wardrobe secure in place by using a screwdriver to tighten as detailed in the diagram. Finally put the Drawer into place as shown in the diagram below.



## Step Nine

Attach the Straps (O) at the back of the wardrobe, using a screwdriver to tighten the M6 Flat Washers (N) and M3.5 x 16mm Pan Head Screws (F) as shown in the diagram.



**PLEASE NOTE:** Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. You must use fixing devices suitable for the type of wall you intend to mount this product to. The screws supplied are to fix the strap to the chest.

**WARNING:** In order to prevent overturning, this product must be used with the wall attachment device provided.

---

## Care and Maintenance

---

### Wood Furniture

Wood displays different grain patterns depending on which way they cut - for example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber - these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.

Wood veneers also allow distinctive patterns to be created on flat surfaces, such as table tops and drawer fronts by the way the slivers are arranged.

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

### How to care for your wood furniture

Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.

Waxed furniture will need to be given a coat of beeswax a couple of times a year to help maintain its luster.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time.

Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping.

---

## Safety Instructions

---

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury. Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent adult. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture. During assembly children should be kept away from the product due to possible risk of injury. Do not use this item if any components are missing or damaged.

As to avoid any instability of the wardrobe's drawer, it is recommended to pull out the drawer from the centre part.

It is recommended that before moving heavy objects to a new location they are completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

This product complies with BS EN 14749 and BS 4875-7.

**If you require any additional information or have any issues with this product please call the John Lewis Helpline on 01244 689949 or email [mail@fwgroup-uk.com](mailto:mail@fwgroup-uk.com)**

John Lewis Partnership 171 Victoria Street, London SW1E 5NN.  
[www.johnlewis.com](http://www.johnlewis.com)