

Mixit tall wardrobe

Stock Code: 80321704 - 80321304 - 80321804 - 80321504


Thank you for purchasing this Mixit wardrobe. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.

Think about your Ceiling Height before assembling your TALL wardrobe.

To build the wardrobe horizontally you need a minimum clearance of 2.44 M height.

To build the wardrobe vertically you need a minimum clearance of 2.40 M height.


Please refer to page 6 for further information.




PRE-ASSEMBLY PREPARATION

Please ensure instructions are read in full before attempting to assemble this product.

Necessary Tools



Screwdriver



Spirit level



Drill



Eye protection



Ruler
tape measure



Small hammer

Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the John Lewis Helpline.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.

This product takes approximately **90 MINUTES** to assemble with **2 PEOPLE**.






















The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.


If you are missing some fittings (cams, dowels and screws) please contact our spare parts helpline on 0330 005 9435. Opening hours are 9am - 5pm Monday to Friday.

For all other queries, please call John Lewis Customer support on 0345 604 9049

Fittings checklist

A  Metal dowel x 12	B  Cam lock x 12	C  Wooden dowel x 16
D  Wedgefix housing x 4	E  Wedgefix dowel x 4	F  Support foot x 4
G  Hanger rail support x 2	H  11mm Euroscrew x 4	I  15mm Screw x 2
L  Spacer x 2	M  x 2	N  Levelling Wedge x 2
O  Bumper x 4	P  25mm Nail x 50	Q  27mm Connector x 4
R  4MAX15 Connect. screw x 4	S  hanging rail x 1	P1  Nail guide x 1
T  clip hinge x 8	I  15mm screw x 16	U  hinge mounting plate x 8


Parts checklist



Step by step assembly instructions

Step One


1. Attach 12x metal dowels (A) into the pre-drilled holes on side panels (2) as shown. Use a screwdriver to turn fitting (A) clockwise to fix.
2. Attach 4x support foot (F) into pre-drilled holes on side panels (2) as shown.
3. Attach 4x hinge mounting plate (U) into pre-drilled holes on side panels (2) as shown. Pay attention to place central hinge at correct position.



Step by step assembly instructions


Step Two

1. Attach 4x wooden dowels (C) into the pre-drilled holes on top/bottom panels (1) as shown.
2. Place the cam lock (B) into the holes on top/bottom panels (1) as shown, arrow pointing towards the bolt.




Step Three

1. Attach 8x wooden dowels (C) into the pre-drilled holes on rails (5) (6) as shown.




Step Four

1. Attach 4x wedgefix housing (D) into the pre-drilled holes on shelf (3) as shown.



Step by step assembly instructions



Measure ceiling hight:



Choose Mounting Method:

Horizontal

Minimum 2.44 M ceiling height clearance required





STEP FIVE



Vertical

Not less than 2.40 M.




STEP ELEVEN




Step Five

1. Attach top/bottom panels (1) and rails (5) (6) onto right side (2) as shown. Ensure metal dowels (A) and wooden dowels (C) are aligned correctly with the holes of matching parts before attaching.
2. Secure top/bottom panels (1) to right side panel (2) using a screwdriver to turn fitting (B) clockwise to fix.



Step Six


1. Attach top/bottom panels (1) and rails (5) (6) onto left side (2) as shown. Ensure metal dowels (A) and wooden dowels (C) are aligned correctly with the holes of matching parts before attaching.
2. Secure top/bottom panels (1) to right side panel (2) using a screwdriver to turn fitting (B) clockwise to fix.



Step by step assembly instructions


Step Seven

1. With help of an assistant, carefully rotate the unit.



Step Eight


1. Position back panel (4) as shown.



Step by step assembly instructions


Step Nine

1. Attach back panel (4) onto back side of the unit using 50x nails (P), with the help of the nail guide (P1).




Step Ten

1. With help of an assistant, carefully stand up the unit upright.



Step Eleven


1. Attach top/bottom panels (1) and rails (5) (6) onto left side (2) as shown. Ensure metal dowels (A) and wooden dowels (C) are aligned correctly with the holes of matching parts before attaching.
2. Secure top/bottom panels (1) to right side panel (2) using a screwdriver to turn fitting (B) clockwise to fix.



Step by step assembly instructions

Step Twelve



1. Attach top/bottom panels (1) and rails (5) (6) onto left side (2) as shown. Ensure metal dowels (A) and wooden dowels (C) are aligned correctly with the holes of matching parts before attaching.
2. Secure top/bottom panels (1) to right side panel (2) using a screwdriver to turn fitting (B) clockwise to fix.






Step by step assembly instructions

Step Thirteen

1. Position back panel (4) as shown.
2. Attach back panel (4) onto back side of the unit using 50x nails (P), with the help of the nail guide (P1).




Important:
The cabinet **MUST**
be 'square' when the
back is attached.



Step by step assembly instructions

Step Fourteen



- 1, Use 2x levelling wedge (N) to level the unit.



Step Fifteen

Fittings have been supplied in order to join units together.

1. Place units together in their final position.
2. Decide position where to drill through using a $\varnothing 5$ mm bit.
3. Push the Connector (Q) into the hole and then screw Bolt (R) in from the other side, tighten with a screwdriver.



Step by step assembly instructions


Step Sixteen

To prevent possible overbalancing we recommend that this unit is secured to a suitable wall by use of two 'L' Brackets (M) fitted to the Top of the unit.

1. Fix the Brackets (M) loosely onto the top of the unit using spacer (L) screw (I) and mark the wall for the wall fixing.
2. Swivel the Bracket (M) away from the wall and drill a hole in the wall using a suitable drill bit and fit your wall fixing.
3. Swivel the Bracket (M) back and fix the Bracket to the wall, then tighten Screw (I)

! IMPORTANT !


Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.
Wall plug and screw not included. **See wall fixing guide at page 14.**



Step by step assembly instructions

Step Seventeen



1. Chose shelf (3) and hanging rail (S) position.
2. Fix 2x hanger rail supports (G) onto the side panels (2) using the screws (H). Fit the hanging rail (S) on the rail supports (G) as shown.
3. Fix 4x shelf support (E) onto the side panels (2). Position the shelf on the shelf support as shown.



Recommended loading capacity:

Single shelf: 20 Kgs


Double shelf: 16 Kgs



Step by step assembly instructions


Step Eighteen

1. Fix 4x hinges (U) to each door using 15 mm screws (I). Repeat with all the doors.



Step Nineteen


1. Hang the clip hinge (T) to the hinge plate (U). Click them together.
To remove the door push the clip hinge button and remove the door carefully.



HINGE ADJUSTMENT INSTRUCTIONS


LATERAL ADJUSTMENT

by screw adjustment.




FRONT-TO-BACK

by slackening and re-tightening
the hinge-arm mounting screw.




VERTICAL ADJUSTMENT

via slot on mounting
plate by slackening and
re-tightening the screws
on mounting plate




Wall fixing - if in doubt seek professional advice




Wood

If fixing to wood make sure that it isn't chipboard as screws can easily pull away from the core structure



Brick or Masonry

Use an appropriate wall plug provided you are sure your wall is sound.



Cavity wall

Special toggle wall plugs are needed. Seek expert advice.

Care and Maintenance

This product has been manufactured using modern manufacturing methods and materials.

To keep your product, looking at its best, we strongly recommend either dusting with a soft cloth, or the use of a damp (not wet) cloth and water containing no more than a 5% soap solution. Dry with a soft clean cloth.

Aggressive chemicals, such as wax furniture polish, abrasive cleaners, bleach or hypochlorate (chlorine) based cleaners, multi purpose cleaners, dilutes, acetone, alcohol and solvent based liquid product should NOT be used, as may result in damage.

Safety Instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten when necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

It is recommended that before moving a heavy object to a new location it is completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

It is recommended by John Lewis that this product is fixed securely to a wall. However this is not compulsory.

No liability will be accepted for damage or injury caused by inadequate fixing or use without fixing.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

John Lewis Partnership 171 Victoria Street London SW1E 5NN

www.johnlewis.com