

# Riley Guest Bed


Stock code 800/65201, 800/65202

Thank you for purchasing this Riley guest bed. Please read the instructions carefully before use to ensure safe and satisfactory operation of the product.

For product support or spare parts please call the John Lewis Helpline;

T: 01244 689949

E: [mail@fwgroup-uk.com](mailto:mail@fwgroup-uk.com)



## Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the John Lewis helpline.


This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.

This product takes approximately **40 MINUTES** to assemble with **2 PEOPLE**.


The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

# Main Bed Parts and Fittings Check List


## Parts




Headboard x 1 (G1)




Footboard x 1 (G2)



Top Rail x 2 (G3)



Side Rail x 2 (G4)




Slats x 1 (G5)

## Fittings

	H1	M6 x 110 MM BOLT	x 4
	H2	M8 x 15 MM BOLT	x 8
	H3	C/B SCREW M4 x 35MM	x 8
	H4	WOOD DOWEL 10 x 30 MM	x 4
	H5	M4 ALLEN KEY	x 4


## Step 1

Attach the top rail (G3) to the head and foot board using bolt (H1) and wooden dowel (H4) to attach.






## Step 2

Secure 2 side rails (H4) on to the head and foot boards using bolts (H2).




### Step 3


Place the wooden slats (G5) on the side rails (P4), fix into place using screw (H3) into the pre - drilled holes along the side rails. (4 on each side).







## Underbed Assembly instructions



### FITTINGS CHECKLIST


	CODE	DESCRIPTION	QTY
	H1	M6 x 75 MM BOLT	4
	H2	M6 x 50 MM BOLT	4
	H3	M6 x 30 MM BOLT	8
	H4	C/B SCREW M4 x 35MM	8
	H5	C/B SCREW M4 x 40MM	2
	H6	DOWEL 10MM x 30 MM	16
	H7	BARREL NUT M6 x 13MM	8
	H8	CASTOR WHEEL	4
	H9	WOOD BUTTON	4

### PARTS CHECKLIST

	CODE	DESCRIPTION	QTY
	G1	HEAD & FOOT PANEL	2
	G2	LEG WITH METAL PLATE	4
	G3	LEG CROSS RAIL	2
	G4	SIDE RAIL	2
	G5	SLAT	1


STEP 1

Place head panel (G1) at the top of the side rail (G4). Join the top and bottom fixing holes with dowels (H6). Join the middle hole with the 50mm bolt (H2) and insert barrel nut (H7) into the side rail (G4), then insert the wood button (H9) into the end of the bolt. Secure 50mm bolt (H2) with Allen Key. (Repeat on foot board panel).




STEP 2

Attach the leg (G2) to the cross rail (G3) using dowel (H6) and barrel nut (H7), secure with bolt (H1). Repeat this for the other leg.



STEP 3



Place the spring and metal plate on the top leg (G2) into the slots on the underbed. Attach the spring with pan head screw (H5) and secure the metal plate with 30mm bolt (H3).



**Caution:** Please do not place the truckle upon its side as it features a spring mechanism that could cause potential injury.



### Step 4

Place the slats (G5) into the underbed and secure in place using M4 x 35mm Screw (H3 x 8), into the pre - drilled holes as shown in the below diagram.



### Step 5

Push the castor wheels (H8) into the top of the legs (G2) as shown in the diagram below.



**Caution:** Please do not place the truckle upon its side as it features a spring mechanism that could cause potential injury.

---

## Care and Maintenance

---

### Wood Furniture

Wood displays different grain patterns depending on which way the wood is cut. For example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber. These are just characteristics of the natural beauty of the wood. Some furniture is deliberately age and rustic.

Wood veneers also allow distinctive patterns to be created on flat surfaces, such as table tops and drawer fronts by the way the slivers are arranged.

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been purchased previously.

### How to care for your wood furniture

Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.

Waxed furniture will need to be given a coat of beeswax a couple of times a year to help maintain its luster.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time.

Our furniture will endure most temperatures in the home, but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping.

---

## Safety Instructions

---

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture, as careless handling can cause damage or injury. Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent adult. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture. During assembly children should be kept away from the product due to possible risk of injury. Do not use this item if any components are missing or damaged.

It is recommended that before moving heavy objects to a new location they are completely disassembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

This product complies with BS EN 1725 1998.

If you require any additional information or have any issues with this product please call the John Lewis Helpline on 01244 689949 or email [mail@fwgroup-uk.com](mailto:mail@fwgroup-uk.com)