Osaka/Felix/Zalo pendant

Thank you for purchasing this product. Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

Warnings.

- This is a double insulated product and does not require an earth.
- It is recommended that this fitting is installed by a qualified electrician.
- This fitting should be fitted in accordance with IEE Regulations and the Building Regulations.
- To prevent electrocution, switch off at the mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electricity supply without you knowledge.
- If you are in any doubt, please consult a qualified electrician.
- If replacing an existing fitting, make a note of the connections.
- Always use the correct type and wattage bulb. Never exceed the wattage stated.
- When changing a bulb, always switch off at the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.
- The bulb and surrounding parts can become extremely hot during use.

Instructions.

- 1. Ensure the house electricity supply is switched off at the fuse board.
- 2. If removing an existing fitting, note down all wiring connections.
- 3. Unscrew the ceiling cap anti-clockwise from the wind up mechanism.
- 4. Drill holes into the ceiling, appropriate for 6 mm rawl plugs (1).
 - Caution: Mind electric cables in the ceiling!

If there is any doubt, use an appropriate

testing apparatus.

- 5. Mount the CABLE LIFT to the ceiling by using 3,5 x 5 mm screws (convex or flat heads)(2).
- 6. Connect the electrical wires by screwing them to the vacant side of the strip connector(3).
- 7. Ensure that no loose strands of wire are left out of the connections.
- 8. Gently tighten the brake screw (5) so that the lamp is held in position by its dead weight.
- 9. Put the ceiling cap on and screw it clockwise with gentle force.
- 10. Fit the bulb type/wattage as indicated on the luminaire.
 - The wattage indicated must not be exceeded.
- 11. Switch on the electricity supply at the fuse board.

Please retain this information leaflet for future reference.

