

SPORTLINE®

SOLO 915 HEART RATE WATCH

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the transmitting equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio technician for help.

Congratulations on your purchase. We commend your efforts on taking steps for healthier living. Measuring your heart rate is fun and easy, and can help manage your 'heart health'.

While this Sportline Solo 915 Heart Rate Monitor Watch works like a standard sports watch, it includes an advanced heart rate sensing technology - **S-Pulse™** - that provides easy and accurate contact heart rate readings.

S-Pulse™ is a patented heart rate sensing technology that measures the electrical signals on your skin – in the same manner that an ECG or electrocardiogram does.

While the Heart Rate Watch attaches to your wrist like other watch products, it does not measure or sense your pulse at your wrist. It instead uses **S-Pulse™ technology** to sense your heart rate by measuring your ECG signal.

POWER DOWN MODE

Your watch was originally shipped in Power Down Mode which allows you to conserve battery life by deactivating the unit when the monitor is not being used for long periods of time.


To deactivate Power Down mode:

1. **PRESS & HOLD** any side button for 3 seconds.
2. To activate, **PRESS & HOLD** the **START/STP & MODE & RESET** buttons for 5 seconds.

How to Measure Your Heart Rate

To get your heart rate reading, just follow these simple steps:

1. Place the Sportline Solo 915 Heart Rate Watch on your wrist, adjusting for a snug, comfortable fit.
2. Place your fingers anywhere on the Sportline Solo 915 Heart Rate Watch's stainless steel face, as shown, and press gently for 3-8 seconds.



Be sure to activate the Heart Rate mode by pressing the bottom metal sensor so that the display flashes. It is best to use the flat 'pads' of your fingers, and not the fingertips.

3. A 'beep' will sound and your heart rate will be displayed. It's that easy!

Because the Sportline Solo 915 Heart Rate Watch is a sensitive monitoring device that reads your ECG signals, reading times will vary. If you don't get a reading in 3-8 seconds, wait a couple of minutes and try again. This gives the Sportline Solo 915 Heart Rate Watch a chance to settle in and pick up your electrical signals.

Your heart rate will remain displayed once measured, and will remain displayed for 7 seconds after you release the sensor button.

- *The Sportline Solo 915 Heart Rate Watch must be attached to your wrist in order for the Heart Rate Measure function to work.*
- *Proper finger pad contact is very important and affects the heart rate reading time.*
- *For those users with dry skin, thick or calloused fingers, low heart rate signal strength (ECG strength), minimal padding on your fingers, or users located in dry environments, please see our Helpful Hints section.*
- *The Heart Rate Measure function is not intended for use or operation in or under water.*

How to Calculate Your Maximum Heart Rate

- Maximum Heart Rate is calculated as: 220 less your age for men ($220 - \text{your age}$) and 226 less your age for women ($226 - \text{your age}$).
- Example of Relative Heart Rate
 - Tom is 30 years old
 - His heart rate measured at 132
 - Maximum heart rate is $220 - 30 = 190$ bpm
 - $132/190 = 70\%$ Relative Heart Rate

To learn more, log onto www.sportline.com


Helpful Hints in Measuring Heart Rate

If you are having difficulty measuring your heart rate, you may want to try the following steps. Try each of these in order until you successfully measure your heart rate:

1. Make sure the Sportline Solo 915 Heart Rate Watch is snugly strapped to your wrist. A loose fit makes it more difficult to properly measure your heart rate. Stop if OK or

2. Press gently with enough pressure to activate the heart rate measure mode. Muscle 'noise' from pressing too hard can make it difficult to measure your heart rate. Stop if OK or
3. Make sure that the metal back of the Heart Rate Watch is laying flat on your skin. Stop if OK or
4. Make sure your wrist and fingers are clean and free from dirt, oils, or lotions. Stop if OK or
5. Stay still, and relax your arms on a stable surface while taking your heart rate. Stop if OK or
6. Clean the front sensors and back metal plate with a mild soap and water or similar cleaning solution. Stop if OK or
7. Moisten with water the pads of the fingers that you are using to contact the sensors on the face of the watch. Stop if OK or
8. Moisten with water the surface between the back metal plate of the watch and the skin on your wrist.

Sportline Solo 915 Heart Rate Watch Features and Button Operation Overview



1. Press the **MODE** button to select the desired feature mode. The Heart Rate Watch feature modes (displays) are:
 - **Time**
 - Set time, date, 12H/24H display mode, and Button Beep ON/OFF
 - **Alarm**
 - Set alarm time, turn alarm ON/OFF, turn hourly chime ON/OFF

- **Chronograph**
 - Run chronograph
 - **CountdownTimer**
 - Set/run timer countdown
2. Once you have selected a feature mode, to change a setting in that mode, hold the **MODE** button down for 2-3 seconds until the display flashes.
 - *When in 'Button Beep ON' mode (watch default), the Sportline Solo 915 Heart Rate Watch will beep when the buttons are pushed.*
 3. Once flashing, to set a feature use the **ST/STP** button to increase and **RESET** button to decrease the setting.
 4. To move to the next setting, press and release the **MODE** button.
 5. To save new settings after completion, hold the **MODE** button down for 2-3 seconds until the display stops flashing.

Setting Time and Date

1. While in the Time mode hold the **MODE** button down for 2-3 seconds until the display flashes.
 2. The 'seconds' display will flash. In order, the settings to enter will be:
 - seconds
 - minutes
 - hours
 - year
 - month
 - day
- Month-day then appear flashing*
- 12Hr (am/pm) or 24Hr (military) time mode
 - Button Beep ON or OFF (buttons beep when pressed when ON, no beeping when OFF)

3. To set the feature, press the **ST/STP** button to increase and **RESET** button to decrease the setting.
4. To move to the next setting, press and release the **MODE** button.
5. After all settings are entered, to save the new settings, hold the **MODE** button down for 2-3 seconds until the display stops flashing.

Setting the Daily Alarm Time

1. While in the Alarm mode, hold the **MODE** button down for 2-3 seconds until the 'hour' display flashes.
2. To set 'hour', press the **ST/STP** button to increase and **RESET** button to decrease the setting.
3. To move to 'minutes', press and release the **MODE** button.
4. After 'hours' and 'minutes' are set, to save, hold the **MODE** button down for 2-3 seconds until the display stops flashing.

Turning the Daily Alarm ON/OFF



Daily Alarm Indicator

1. While in the Alarm mode, press the **ST/STP** button once to turn the Daily Alarm ON or OFF.
2. When the Daily Alarm Indicator appears, the daily alarm is ON. The Watch will start beeping at the designated alarm time for 30 seconds. To stop the beeping early, simply press any button (except the **LIGHT** button).

Turning the Hourly Chime ON/OFF



Hourly Chime Indicator

1. While in the Alarm mode, press the **RESET** button once to set the hourly chime ON or OFF.
2. When the Hourly Chime Indicator appears, the hourly chime is ON, and the Watch will beep at the top of each hour.

Using the Chronograph Feature

The Chronograph feature measures elapsed time from a zero starting point. The maximum counting range of the chronograph is 99 hours, 59 minutes and 59 seconds.

To use the Chronograph, press the **MODE** button to select the Chronograph mode. The Watch can now be used to record an elapsed length of time.

1. Press the **RESET** button to reset counter to '0'.
2. Press the **ST/STP** (start/stop) button once to start timing.
3. Press the **ST/STP** (start/stop) button to stop timing.
4. To reset the chronograph to '0' press the **RESET** button.

Using the Countdown Timer Feature

The Countdown Timer tracks a fixed period of time by counting down from a user-set time period.

- *The Watch is set at a 1 minute default.*

The countdown time can be set up to 99 hours, 59 minutes and 59 seconds.

Setting the Countdown Timer

To use the Countdown Timer, press the **MODE** button to select the Timer mode.

1. When in Countdown Timer mode, press the **MODE** button down for 2-3 seconds until the 'hour' digit flashes.
2. To set 'hour', press the **ST/STP** button to increase and **RESET** button to decrease the setting .
3. To move to 'minutes', press and release the **MODE** button.
4. To move to 'seconds', press and release the **MODE** button.
5. After 'hours', 'minutes', and 'seconds' are set, hold the **MODE** button down for 2-3 seconds until the display stops flashing. The settings are now saved.

Running the Countdown Timer

1. Once a countdown time has been set, press the **ST/STP** button once to start the Timer.
 2. The Timer will start counting from the countdown time down to '0'.
 3. At 5 seconds before finish, the Watch will start to beep. This will continue for 15 seconds.
 4. To stop the beeping early, press any button (except the **LIGHT** button).
 5. The Countdown Timer will then return to the original countdown time.
- *To reset the Countdown Timer to the original countdown time, press the **RESET** button once when the Timer is stopped.*
 - *To reset the Timer while the Timer is running, press the **ST/STP** button to stop the counting, then press the **RESET** button.*

Using the Calorie Feature

1. While in the Time mode, press the MODE button 5 times until the Calorie (CA) screen is displayed.
2. Press the ST/STP button to start (or stop) the Calorie timer.
3. Calories burned are calculated based on your current heart rate. Therefore, it is best to update your heart rate as often as possible (your calories burned will be displayed beneath the calorie timer next to the CA).
4. When the Calorie Timer is stopped, press the RESET button to reset the calorie timer and counter.

Note: The single best factor to measure calorie expenditure is your heart rate.

As a result, it is important to:

- 1) Acquire your heart rate prior to exercise
- 2) Acquire your heart rate during warm up
- 3) Acquire your heart rate during exercise
- 4) Acquire your heart rate during cool down

Care and Maintenance

To ensure proper function of your Sportline Solo 915 Heart Rate Watch:

- Avoid rough usage or severe impacts to the Watch
- Keep the front sensor and back metal plate free from dirt, oils, or other contaminants
- Periodically clean the Watch, using a soft cloth, with a mild soap and water or similar cleaning solution
- Keep the Watch out of extreme heat or cold
- Do not expose the Watch to intense direct sunlight for long periods of time

- Do not expose the Watch to chemicals such as gasoline, alcohol, or solvents

Specifications

Current Time Mode

- Hour, minute and second
- Month, day, day of week and year
- 12 / 24 hour format selectable
- Month-day/Day-month selectable
- Auto calendar from year 2000 to 2099
- Hourly Chime on the hours

Heart Rate Alert Mode

- Measuring range: 43 to 200 beats per minute

Daily Alarm Mode

- Daily Alarm: 1 daily alarm
- Alarm Duration: 30 seconds

Chronograph Mode

- Resolution: 1/100 second
- Counting range: 99 hours, 59 minutes, 59 seconds
- Measuring mode: Elapsed time

CountdownTimer Mode

- Resolution: 1 second
- Limit: 99 hours, 59 minutes, 59 seconds
- Alarm sound: 1 beep at the 5,4,3,2 and 1 second(s), 3 beeps at 0 second for 10 seconds.

Other

- Electro-luminescent/EL backlight
- Water resistant to 30 meters

The Heart Rate Measure function is not intended for use or operation in or under water.

Battery

Battery replacement will be required from time to time, and should occur when:

- The display fades in part or completely
- The Heart Rate function will not activate

To replace the battery of your Sportline Solo 910 Heart Rate Watch, we recommend that this be done by a watch repair service center. This will ensure that the water resistance will be retained after battery replacement.

The watch uses standard lithium replacement CR2032 batteries.

NOTE: Estimated battery life is approximately one year. However, the EL “Backlight” and “Heart Rate” features require a higher rate of power consumption. Continuous holding down of these buttons or high frequency usage of these features will shorten the battery life.

CAUTION – Battery Safety Information

- Non-rechargeable batteries are not to be recharged
- Rechargeable batteries must be removed before recharging
- Rechargeable batteries should only be recharged under adult supervision
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries
- Exhausted batteries are to be removed
- Do not mix old and new batteries
- Do not dispose of batteries in fire; batteries may explode or leak
- Do not dispose of product in fire; batteries may explode or leak
- If this product will not be used for an extended period of time, remove the batteries from the product

- The supply terminals are not to be short-circuited
- Batteries are to be inserted with correct polarity
- Clean the battery contacts and also those of the product prior to battery installation
- As always, dispose of batteries in an eco-friendly manner

How the Watch Works

It is useful to understand the basics of how the **S-Pulse™** sensing technology – as it will perform differently on people of different age, skin type, body type, ECG or electro-cardiogram signal strength, among others.

The **S-Pulse™** technology measures the electronic signals that pass through your body – that result from the beating of your heart. Many are familiar with the ECG waveform – from either personal experiences while at the hospital, or from popular television medical shows. It is this same signal that passes through your body. This measurement is obtained by the Watch's three metal sensors. The back metal plate of the Watch wrist is actually a primary sensor that measures these electronic signals off your arm.

The 'ECG' measurement is done when you place your fingers from one hand on the top sensor on the Watch that is attached to your opposite arm. This creates a loop across your body that the Watch can now read.

- *The Sportline Solo 915 Heart Rate Watch must be attached to your wrist in order for the Heart Rate Measure function to work.*

Patents

The Heart Rate Watch and **S-Pulse™** technology are result of and protected by the following patents:

US: 5,738,104 & 5,876,350

Europe: EPO 0861045B1

GUARANTEE CERTIFICATE

For purchases made in the U.S.

If at any time within one (1) year from the purchase date of this product, it fails to perform properly because of defects in material or manufacturing, return it prepaid to:

EB SPORT GROUP, 585 Oak Ridge Road, Hazleton, PA 18202

Complete this Guarantee Certificate and enclose it (or a copy of it) with the product.

(PLEASE PRINT CLEARLY)

NAME _____

TEL _____

ADDRESS _____

CITY _____

STATE _____ ZIP _____

STORE PURCHASED FROM _____

DATE OF PURCHASE _____

PROBLEM WITH PRODUCT _____

REPLACEMENT

This product has been carefully designed, manufactured and packaged. If any parts are missing or damaged, please contact us

at the address above and we will replace the unit at no charge.
(Guarantee does not cover crystal or battery.)

For purchases made in the UK:

Should you experience problems with this item, please return it to the point of purchase. This will not affect your statutory rights. Alternatively return it to the address shown below for a repair/replacement: EB Brands UK, Berkeley Business Park, Wainwright Road, Worcester WR4 9FA

The purpose of the crossed-out wheelie bin symbol is to remind us that most electrical products, and batteries, contain trace elements (including Mercury – Hg, Cadmium – Cd and Lead – Pb) which could be harmful to our environment and therefore our health. We must all be careful to dispose of them responsibly in a specifically designated way – either using a collection scheme or into the correctly labelled civic amenity (NOT into general waste) – this will help your local authority to arrange to recycle or dispose of them in the appropriate manner.



www.sportline.com

Sportline® is a trademark of SPORTLINE, a division
of EB Sport Group, Yonkers, NY 10701

Distributed in the UK by
EB Brands UK, Worcester, WR4 9FA UK
All Rights Reserved. ©2009

SP4964IS01ROD