


# Napoli bedside chest

Stock Code: 80310601 - 80310602 - 80310603


Thank you for purchasing this Napoli bedside chest. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



## PRE-ASSEMBLY PREPARATION

Please ensure instructions are read in full before attempting to assemble this product.

### Necessary Tools



Screwdriver



Eye protection



Ruler/tape  
measure



Small hammer

Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the John Lewis Helpline.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.














This product takes approximately **45 MINUTES** to assemble with **1 PEOPLE**.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.


Read this leaflet in full before commencing assembly.

If you are missing some fittings please contact our spare parts helpline on 0330 005 9435. Opening hours are 9am - 5pm Monday to Friday.

# Fittings checklist

<div>A</div>  <p>Metal dowel x 22</p>	<div>B</div>  <p>Long cam lock x 2</p>	<div>C</div>  <p>Middle cam lock x 14</p>
<div>D</div>  <p>Short cam lock x 6</p>	<div>E</div>  <p>Wooden dowel x 26</p>	<div>F</div>  <p>25mm Nail x 30</p>
<div>G</div>  <p>Nail guide x 1</p>	<div>H</div>  <p>11mm Euroscrew x 8</p>	<div>I</div>  <p>Support foot x 4</p>
<div>L</div>  <p>30mm Screw x 8</p>	<div>M</div>  <p>30mm Screw x 16</p>	
 <p>410mm runners x1</p>		
 <p>360mm runners x1</p>		

# Parts checklist




---

## Step by step assembly instructions

---

### Step One

1. Attach 8x metal dowels (A) into the pre-drilled holes on top panel (1) and bottom panel (17) as shown. Use a screwdriver to turn fitting (A) clockwise to fix.




---

### Step Two

1. Attach 6x wooden dowels (E) into the pre-drilled holes on side panel (2) as shown.
2. Place 4x cam lock (C) into the holes on side panel (2) as shown, arrow pointing towards the bolt. Attach 2x metal dowels (A) into the pre-drilled holes on side panel (2) as shown. Use a screwdriver to turn fitting (A) clockwise to fix.

Repeat for the other side panel




---

## Step by step assembly instructions

---

### Step Three


1. Attach 4x wooden dowels (E) into the pre-drilled holes on rails (4) as shown.
2. Place 4x cam lock (C) into the holes on side panels (4) as shown, arrow pointing towards the bolt.



---

### Step Four



1. Attach 4x wooden dowels (E) into the pre-drilled holes on rails (3) (5) as shown.
2. Place 2x cam lock (C) into the holes on side panels (5) as shown, arrow pointing towards the bolt.
3. Place 2x cam lock (B) into the holes on side panels (3) as shown, arrow pointing towards the bolt.



## Step by step assembly instructions

### Step Five

1. Attach 2x metal dowels (A) into the pre-drilled holes on one the two rail (18) as shown.
2. Attach 2x metal dowels (A) into the pre-drilled holes on one the two rail (7) as shown.






## Step by step assembly instructions


### Step Seven

1. Attach rails (3) (4) (5) onto side panels (2) as shown. Ensure metal dowels (A) and wooden dowels (E) are aligned correctly with the holes of matching parts before attaching. Secure rails (3) (4) (5) to side panels (2) using a screwdriver to turn fitting (B) C) clockwise to fix.



### Step Eight

1. Attach top panel (1) onto side panels (2) as shown. Ensure metal dowels (A) and wooden dowels (E) are aligned correctly with the holes of matching parts before attaching. Secure top panel (1) onto side panels (2) using a screwdriver to turn fitting (C) clockwise to fix.






## Step by step assembly instructions


### Step Nine

1. Attach bottom panel (17) onto side panels (2) as shown. Ensure metal dowels (A) and wooden dowels (E) are aligned correctly with the holes of matching parts before attaching. Secure bottom panel (17) onto side panels (2) using a screwdriver to turn fitting (C) clockwise to fix.



### Step Ten


1. Position back panel (6) as shown
2. Attach 4x support foot (I) to bottom (17) with 8x screw(M).





## Step by step assembly instructions

### Step Eleven

1. Attach back panel (6) onto back side of the unit using 30x nails (F), with the help of the nail guide (G).





**Important:**  
The cabinet **MUST** be 'square' when the back is attached.



### Step Twelve

1. Fix runner parts (Z1) (Z2) (X1) (X2) through holes shown in the detail view using euroscrews (H).




---

## Step by step assembly instructions

---

### Step Thirteen


1. Attach 2x wooden dowels (E) into the pre-drilled holes on drawer sides (11) (12) as shown,
2. Place the cam lock (D) into the holes on drawer sides (11) (12) as shown, arrow pointing towards the bolt,
3. Attach 2x metal dowels (A) into the pre-drilled holes on drawer front (8). Use a screwdriver to turn fitting (A) clockwise to fix



---

### Step Fourteen


1. Fit the RH (11) and LH (12) drawer sides to the drawer back (10) using 30 mm screws (L),



## Step by step assembly instructions


### Step Fifteen

1. Slide drawer bottom panel (9) into the drawer box grooves, pay attention to correct position.
2. Position drawer front (8) onto drawer box, turn locking nuts (D) clockwise to lock.



### Step Sixteen


1. Attach 4x wooden dowels (E) into the pre-drilled holes on drawer sides (14) (15) as shown.
2. Place the cam lock (D) into the holes on drawer sides (14) (15) as shown arrow pointing towards the bolt,
3. Attach 4x metal dowels (A) into the pre-drilled holes on drawer front (13). Use a screwdriver to turn fitting (A) clockwise to fix.



## Step by step assembly instructions


### Step Seventeen

1. Fit the RH (14) and LH (15) drawer sides to the drawer back (16) using 30 mm screws (L),



### Step Eighteen

1. Slide drawer bottom panel (9) into the drawer box grooves, pay attention to correct position.
2. Position drawer front (13) onto drawer box, turn locking nuts (D) clockwise to lock.




---

## Step by step assembly instructions

---

### Step Nineteen


1. Pull out the runners, then ensure plastic securing pegs are to the OUT position.



## Step by step assembly instructions

### Step Twenty

1. Slide the drawer box tilted until the stop.
2. Attach the drawer box leaning on the runners.
3. Push the plastic securing pegs in the IN position





---

## Step by step assembly instructions

---

### Step Twenty-one

1. Use the small plastic knob of the runners to align the drawers if needed.





## Safety Instructions

---

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten when necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

It is recommended that before moving a heavy object to a new location it is completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

This product is designed to be fixed securely to a sound wall in the manner stated.

It must under no circumstances be used free-standing. No liability will be accepted for damage or injury caused by inadequate fixing or use without fixing.

---

## Care and Maintenance

---

This product has been manufactured using modern manufacturing methods and materials.

To keep your product, looking at its best, we strongly recommend either dusting with a soft cloth, or the use of a damp (not wet ) cloth and water containing no more than a 5% soap solution. Dry with a soft clean cloth.

Aggressive chemicals, such as wax furniture polish, abrasive cleaners, bleach or hypochlorate (chlorine) based cleaners, multi purpose cleaners, dilutes, acetone, alcohol and solvent based liquid product should NOT be used, as may result in damage.

**PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE**

John Lewis Partnership 171 Victoria Street London SW1E 5NN  
[www.johnlewis.com](http://www.johnlewis.com)