

Caring for your product

We recommend cleaning with a soft dry cloth. Do not use abrasive materials as these will damage the finish.


Replace bulbs from John Lewis or established brand of the same type and compatibility.

Aftercare and Troubleshooting

Please ensure all screws and small pieces are properly tightened to the product.

When changing a bulb, always switch off the mains and allow the bulb to cool down before handling.

A bulb's watt rating indicates how much energy it uses. The higher the watt, the more energy it requires. Lumens is a measure of brightness. The higher the number of lumens, the brighter the light.



Specification

Max. power: 120W

Voltage: 220–240V~50Hz

IP rating: 20

Weight: 15.10 kg



5 year guarantee

At John Lewis & Partners we test every light to high quality standards so we are able to offer you a 5 year guarantee.

Recycling

This symbol  indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.




John Lewis Partnership
171 Victoria Street
London SW1E 5NN
johnlewis.com

Made in China

Please retain these instructions for future reference.




HECTOR 3 LIGHT FLOOR LAMP USER GUIDE



Introduction

Thank you for purchasing this Hector 3 Light Floor Lamp.
Please read the instructions carefully before use to ensure
safe and satisfactory operation of this product.

Warnings


















This lamp is for indoor use only.

This product is Class II.

The supply cord cannot be replaced. If the cord is damaged, the floor lamp should be destroyed in order to avoid a safety hazard.

Always use the correct type and rated power bulb. Never exceed the rated power stated.

Dispose of used bulbs carefully.

Parts list	Description	Image	Quantity
A	Shade		3 PCS
B + E	Tube+Part		3PCS
C	Screw		3PCS
D	Key		1PC
F + H	Tube+Part		2PCS
G	Tube		1PC
I	Pole		1PC
J K	Pole		2PCS
L	Washer		1PC
M	Base		1PC
N	Washer		1PC
O	Nut		1PC
P	Wrench		1PC
Q	Screw		1PC
R	Wrench		1PC


Recommended bulb

3 × 10 watt E27 LED bulbs


Bulbs replaceable

Bulbs not included


Product assembly




1. Carefully unpack the carton, making sure all parts are included before assembly. Place lamp parts on a flat surface.



2. Insert tube (B) into shade (A). Tighten the pre-set screw (C) with allen key (D) to secure tube (B) and shade (A) together.




3. Insert tube (F) into tube (B) and turn part (E) until tight to secure tube (F) to tube (B).



4. Insert tube (G) into tube (F) and turn part (H) until tight to secure tube (G) to tube (F).


Repeat step 4 to assemble the remaining arm.

Note: 1 arm will only include tubes B & G while the other 2 arms include tubes B, F, & G.




5. Carefully insert upper lamp body into pole (K) and tighten pre-set screw (Q) until tight with Allen wrench (R).


Note: You may need to insert any excess cord gently into pole (K) before tightening the parts together.




6. Screw pole (J) into pole (K) until tight.



7. Screw pole (I) into pole (J) until tight. You may need to pull any excess cord gently through the poles so that these two parts fit.



8. Insert pole (I) into base (M) & washer (L). Tighten nut (O) to washer (N) using wrench (P).



NOTE: The screw hole of tube (K) should face towards the back of the lamp in the same direction as the cord coming out of the back of the base and you may need to pull any excess cord the pole from base.

01

02