

Product information

- Indoor use only
- Non-dimmable
- Clean the fitting with a soft dry cloth. Do not use abrasive chemical cleaners as this will damage the finish


Aftercare and Troubleshooting

If there are technical issues with this product that you can't solve, please contact your nearest John Lewis & Partners shop or call Technical Support on 03301 230106.


Specification

Max power: 5.9W
Rated input: 220 –240V, 50Hz
IP rating: 20
Weight: 0.48kg
200 lumen output
Colour temperature: Warm white (3000K)
This product contains a light source of energy efficiency class G
For further information please visit:
www.lighting-info.co.uk/101165

Replaceable (LED only) light source by a professional




Replaceable control gear by an end-user



2-year guarantee

At John Lewis & Partners we test every light to high quality standards. That means we can offer you a 2-year guarantee.

Recycling

This symbol  indicates that this product should not be treated as normal household waste and it should be recycled. John Lewis & Partners do not operate instore take back, but as members of the Distributor Take Back scheme have funded the development and upgrade of recycling facilities across the UK. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk.

John Lewis Plc
171 Victoria Street
London SW1E 5NN
johnlewis.com

Made in China




25/05/2022

Please retain these instructions for future reference.

little home
at John Lewis

WALL FITTED TASK LAMP USER GUIDE



2
YEARS

Product Code:
41350606
41350607


Getting started

Thank you for purchasing this John Lewis & Partners product. For your safety, and to make sure everything is working properly, please read the instructions carefully before use.

Warnings

This product is only suitable for connection to a 240V~50Hz supply in accordance with current IEE Wiring Regulations. It is for indoor use only, and not suitable for a bathroom location.

This plug-in wall light is designed for easy installation to a wall or other stable vertical surface. No electrical wiring is required, but fixing holes need to be drilled into the mounting surface.

This product is Class 3 (low voltage)  and uses a plug-in transformer. Under no circumstances must this be replaced by a standard 13amp UK type plug. This will cause a safety hazard.


If the mains cable becomes damaged it must only be replaced by a technically competent, qualified person. In the case of a Class III rated product, a new cable set may be available - please check with your retailer.

Do not plug into the mains until your lamp is fully assembled. If you are in any doubt about your competence please consult a qualified electrician. If any modification is made it will invalidate the warranty and may render the product unsafe.

When moving or cleaning, always switch off at the mains and allow the LEDs to cool before handling.

Important: Children can become entangled in loose cables. Ensure excessive loops of cable are secured against the wall using retaining clips or otherwise tidied away.

Guide to wall mounting & fixings

KEY INFORMATION 

Different wall materials require different types of screws / fixings. Please ensure you use the correct screws / fixings for your type of walls and seek professional advice if you are not sure.

Failure of the product due to incorrect fixings is the responsibility of the installer.


Important: When drilling into the walls always check that there are no hidden wires and pipes etc. Take care when drilling on glazed tile surfaces in case of drill slips.

FIXINGS

Use the relevant type of wall plug, depending on if your walls are made of brick, breezeblock, concrete, stone or wood:


General purpose wall plug

Suitable for solid, masonry walls.




Plasterboard wall plug



For light loads on to plasterboard partitions.



Cavity fixing wall plug

For plasterboard partitions or hollow wooden doors.



Parts list					
Description	Image	Qty	Description	Image	Qty
Light fitting		x 1	Retaining clips		x 2

Product assembly

Step 1

Carefully unpack the carton, making sure all the parts are present before assembly.


Decide on the position of the light fitting. This needs to be where the product can be mounted to a suitable surface to support the product weight and where the plug can reach a mains outlet socket.

Step 2

Remove the two side screws (A) at the back of the product to separate the mounting bracket (B). Use the mounting bracket as a template to mark the screw holes. Make the screw holes and fit the wall plugs, taking care not to damage concealed wiring and pipes.

Step 3


Secure the mounting bracket to the wall using the appropriate screws (C).



Step 4

Refit the fitting onto the mounting bracket and secure with the screws removed in Step 2. Take care not to trap the flexible cable.

IMPORTANT: Children can become entangled in loose cables. Ensure excessive loops of cable are secured against the wall using the supplied retaining clips (D).




Step 5

Connect the driver to the product (E). Plug in the LED driver.

Your lamp is now ready for use.



NOTE: The angle of the shade can be adjusted up and down as needed.



LED driver replacement

Obtain suitable replacement driver - ensuring all technical specifications match the existing item. Disconnect the old driver from the connector on the cable. Re connect the new driver.